

ERS, pipe earthing clamp; for steel and copper pipes



item code	material	screw	for cond. Ø [mm]	ps [pcs]	ref.
ERS/M5-1/8"gv	gv	M5	1/8"	50	076 961
ERS/M5-1/4"Gv	gv	M5	1/4"	50	076 962
ERS/M6-3/8"gv	gv	M6	3/8"	50	076 963
Ers/M6-1/2"gv	gv	M6	1/2"	50	064 518
Ers/M6-3/4"gv	gv	M6	3/4"	50	064 519
Ers/M6-1"gv	gv	M6	1"	50	064 520
Ers/M6-5/4"gv	gv	M6	5/4"	50	064 521
Ers/M6-6/4"gv	gv	M6	6/4"	50	064 522
Ers/M6-2"gv	gv	M6	2"	25	064 523
Ers/M6-2 1/2"gv	gv	M6	2 1/2"	25	064 524
Ers/M5-1/8"Cu	Cu	M5	1/8"	50	064 473
Ers/M5-3/8"Cu	Cu	M5	3/8"	50	064 474
ERS/M5-1/4"Cu	Cu	M5	1/4"	50	064 475
Ers/M6-1/2"Cu	Cu	M6	1/2"	50	064 476
Ers/M6-3/4"Cu	Cu	M6	3/4"	50	064 477
Ers/M6-1"Cu	Cu	M6	1"	50	064 478
Ers/M6-5/4"Cu	Cu	M6	5/4"	50	064 479
Ers/M6-6/4"Cu	Cu	M6	6/4"	50	064 480

with cleat



item code	material	for cond. Ø [mm]	ps [pcs]	ref.
ERS3/4"fv	fv	1/2"	75	064 005
ERS1"fv	fv	1"	75	064 002
ERS5/4"fv	fv	5/4"	50	064 006
ERS6/4"fv	fv	6/4"	50	064 007
ERS2"fv	fv	2"	50	064 004

with contact screw coupling



item code	material	for cond. Ø [mm]	ps [pcs]	ref.
ERS+KS1/2"fv	fv	1/2"	25	006 342
ERS+KS3/4"fv	fv	3/4"	25	006 343
ERS+KS1"fv	fv	1"	25	006 344
ERS+KS5/4"fv	fv	5/4"	20	006 346
ERS+KS6/4"fv	fv	6/4"	25	006 345
ERS+KS2"fv	fv	2"	25	006 347
ERS+KS2 1/2"fv	fv	2 1/2"	15	006 348
ERS+KS3"fv	fv	3"	15	006 349