

Air sampling smoke detection system **TITANUS MICRO·SENS®**



Technical Manual

Air Sampling Smoke Detection System

TITANUS *MICRO-SENS*[®]

Rev.a

Technical Manual

WAGNER Group GmbH

Schleswigstraße 1 - 5

D-30853 Langenhagen

Telephone +49 (0) 511 / 97383-0

Telefax +49 (0) 511 / 97383-140

E-Mail support@wagner.de

Internet www.wagner.de

item number: 69-30-0525

dated: 01/09

supersedes: 12/06

Contents

0	General	0 – 1
0.1	Introduction	1
0.2	Safety Information	1
0.3	Guarantee	2
0.4	Copyright	2
0.5	Packaging	3
0.6	Disposal	3
1	Product Description	1 – 1
1.1	Characteristics of the TITANUS MICRO·SENS® aspirating smoke detection system	1
1.2	Areas of Application	3
2	Technical Description	2 – 1
2.1	System Description	1
2.1.1	Function	2
2.2	TITANUS MICRO·SENS® and Accessories	6
2.2.1	Overview	6
2.2.2	TITANUS MICRO·SENS® air sampling smoke detection system	7
2.2.3	Detector Box	9
2.2.4	Diagnostics tool	12
2.2.5	Parallel Displays	13
2.2.6	Reaction Indicator	14
2.3	Pipe system	15
2.3.1	Overview	15
2.3.2	Aspiration apertures for room monitoring	17
2.3.2.1	Aspiration reduction films	17
2.3.2.2	Aspiration reduction clips	18
2.3.3	Ceiling duct for concealed mounting	19
2.3.4	Air filters for dusty areas	20
2.3.5	Air return for pressure differences and air pollution	21
2.3.6	Noise suppressor	22
2.3.7	Steam trap for humid areas	23
3	Technical Data	3 – 1
3.1	TITANUS MICRO·SENS®	1
3.2	TITANUS MICRO·SENS® detection box	3
3.3	Accessories – TITANUS MICRO·SENS®	4
3.4	Pipe System – TITANUS MICRO·SENS®	6

Contents

4	Design	4 – 1
4.1	General	1
4.1.1	Regulations	2
4.1.2	Pipe system	3
4.1.3	Air flow monitoring	7
4.1.4	Sensitivity	9
4.1.5	Design Limits	10
4.2	Project planning	11
4.2.1	Project planning guidelines	11
4.2.1.1	Determining the necessary accessories	11
4.2.2	Pipe accessories	12
4.2.3	Sensitivity and pipeline project planning	13
4.2.3.1	Pipeline project planning with pipe accessories	13
4.2.4	Aperture diameter	17
4.3	Special project planning	19
4.3.1	Project planning for individual aperture monitoring	19
4.3.1.1	I-Pipe system	19
4.3.1.2	U-Pipe system	21
4.3.1.3	M-Pipe system	23
4.3.1.4	Double-U-Pipe system	25
4.3.2	Simplified pipe design	27
4.3.2.1	I-Pipe system	27
4.3.2.2	U-pipe system	28
4.3.2.3	M-pipe system	29
4.3.2.4	Double-U-pipe system	30
4.3.3	Design for Forced Air Flow	31
4.4	Power Supply	35
5	Installation TITANUS MICRO·SENS®	5 – 1
5.1	General	1
5.2	Installation site	2
5.2.1	Fitting the TITANUS MICRO·SENS® air sampling smoke detector	2
5.2.2	Connecting the air sampling pipe	5
5.3	Incorporation and electrical connection of additional modules	6
5.4	Connection to CFDU, with reset button	9
5.5	Incorporating the reset board	10
5.5.1	Connection to a CFDU, with reset board	12
5.6	Incorporating the reset and isolating button board	13
5.6.1	Function switching plan, reset and isolating button board	14

Contents

5.7	Incorporating the relay board RU-1/RU-2	15
5.7.1	Function switching plan, relay board RU-1	16
5.7.2	Function switching plan, relay board RU-2	17
5.8	Using TITANUS MICRO·SENS® in the AlgoRex® fire alarm system	18
5.8.1	Collective Connection	18
5.8.2	Function switching plan, collective connection	19
5.8.3	Use of the TITANUS MICRO·SENS® with AlgoRex® line components	20
5.8.3.1	Installation of AlgoRex® line components into the TITANUS MICRO·SENS® additional housing	20
5.8.3.2	TITANUS MICRO·SENS® and AnalogPLUS technology	21
5.8.3.3	TITANUS MICRO·SENS® and interactive technology	22
5.9	TITANUS MICRO·SENS® in a network	23
5.9.1	Fitting the network module into the TITANUS MICRO·SENS® additional housing	23
5.9.2	Connecting the Network Module	24
5.10	Parallel displays	25
5.10.1	Connecting the parallel displays to TITANUS MICRO·SENS®	25
5.10.2	Parallel display housing	26
5.10.3	Electrical connection	27
5.11	Reaction indicator	28
5.11.1	Addressing the reaction indicators	28
5.11.2	Connecting the reaction indicator to the TITANUS MICRO·SENS®	29
5.12	Inserting the detection unit in the device base unit	30
5.13	Settings	31
5.13.1	Detection Unit	31
5.13.1.1	Setting reaction sensitivity	32
5.13.1.2	Delay time for triggering the alarm	32
5.13.1.3	Threshold for air flow monitoring	32
5.13.1.4	Delay time for air flow fault	33
5.13.1.5	Action-Alarm Threshold	33
5.13.1.6	Fault display	33
5.13.1.7	Dynamic air flow	34
5.13.1.8	ROOM-IDENT	34
5.13.1.9	LOGIC·SENS	34
5.13.1.10	Fire Alarm threshold after ROOM-IDENT	35
5.13.1.11	Setting the ventilator voltage	35
5.13.1.12	Inputting the current air pressure	36
5.13.1.13	Inputting height above Normal Sea Level (NN)	36
5.13	Data Logging	37

Contents

6	Installation Pipe System	6 – 1
6.1	Linear expansion of the pipe system	3
6.2	Patented air sampling points	5
6.3	Ceiling lead through	7
6.4	Monitoring in forced air flow systems (ventilation or climatic applications)	9
6.4.1	Detection at air inlets/outlets	9
6.4.2	Detection in bypass systems	9
6.5	Filter	10
6.5.1	Installation of air filter, type LF-AD-x	10
6.5.2	Mounting of the special filter type SF-400/650	11
6.6	Air return	12
6.7	Noise suppressor	13
6.8	3-Way ball valve	14
6.9	Steam trap	15
6.10	Test adapter	16
7	Commissioning	7 – 1
7.1	Commissioning the detection unit	1
7.1.1	Plug and Play Commissioning	2
7.1.2	Commissioning with the diagnostics tool	2
7.2	Installing diagnostics software	3
7.3	Air flow sensor adjustment	5
7.3.1	Air Pressure-Independent Adjustment	5
7.3.2	Air Pressure-Dependent Adjustment	6
7.4	Testing the detection unit and alarm forwarding	8
7.5	Testing air flow monitoring	9
7.6	Testing fault forwarding	10
7.7	Testing the air flow sensory analysis function	11
7.7.1	Preparations for function testing	11
7.7.2	Carrying out function testing	13
7.8	Commissioning fire seat location	15
7.9	Commissioning the reaction indicators	19

Contents

8	Maintenance	8 – 1
8.1	Visual check	1
8.2	Testing detector and alarm forwarding	1
8.3	Testing pipe system	1
8.4	Exchanging the detection unit	2
8.5	Exchanging the type AF-TM air filter for the device base	3
8.6	Changing the filter on the LF-AD-x air filter	4
8.7	Changing the filter on the SF-400/650 special filter	5
8.8	Pipe system blow through process	6
8.9	Checking the air flow sensor adjustment	7
8.10	Testing fire seat location and the reaction indicators	9
8.11	Testing Air Flow Monitoring	10
8.12	Testing Fault Forwarding	10
8.13	Maintenance Intervals	10

Appendix

Air Pressure Adjustment Tables

Projection Tables

System Product List

Certificate of Approval of Components and Systems

EMC Declaration of Conformity

Inspection Protocol

Glossary

Conformity certification pursuant to EU

0 General

0.1 Introduction

This manual is for installers of air sampling smoke detection systems, in particular for engineers, technicians, and fitters etc. who have technical knowledge in the field of smoke detection technology but who are possibly working with this device for the first time.

For damage and faults resulting from the non-observance of this manual WAGNER Group GmbH, called WAGNER in the following, does not assume liability.

This manual refers to the air sampling smoke detection systems TITANUS MICRO·SENS®. These systems may only be used for early and very early smoke detection. As the smoke detection systems are from one series, TITANUS MICRO·SENS® is described here.

0.2 Safety Information

The following symbols identify parts of the text in this manual which require special attention so that damage can be avoided and so that operations can run smoothly.



This symbol warns against actions which might cause damage if it is ignored.



This symbol warns against actions which could cause operational breakdowns if it is ignored.



Operational improvements can be achieved if this symbol is observed.

0.3 Guarantee

The manual is subject to technical modification without notice and makes no claim to completeness.

In principle our “Terms and Conditions of Supply and Assembly” apply. No claims under the guarantee or for liability can be made for damage to persons or property if they are based on one or more of the following causes:

- insufficient observance of the instructions about the design, assembly of the aspirating smoke detection system, assembly of the pipe system, commissioning and maintenance
- use of the aspirating smoke detection system in contravention of the intended use
- insufficient monitoring of working parts
- improperly executed repairs
- unauthorised constructional changes to the aspirating smoke detection system
- force majeure

0.4 Copyright

The copyright in this Technical Manual remains with WAGNER.

The manual is designed exclusively for the assembler and his colleagues.

Reproduction of the manual, including extracts, is not allowed. Copying or distribution of the manual in any form is only allowed with permission in writing from WAGNER.

0.5 Packaging

The individual air sampling smoke detection systems are packed in accordance with the anticipated transport conditions. Exclusively environmentally friendly materials were used for the packaging.

The packaging is intended to protect the air sampling smoke detection system from being damaged until it is installed. For that reason, it should only be removed from its packaging shortly before installation.

The packaging material is to be disposed of in accordance with applicable statutory provisions and local regulations.

- Dispose of the packaging materials in an environmentally friendly manner.
- Observe local disposal regulations.



Packaging materials are valuable raw materials and in many cases can be re-used or expediently processed and recycled. Improper disposal of packaging materials can harm the environment.

0.6 Disposal

If no take-back or disposal agreements have been made, disassembled components are to be taken for recycling:

- Take metal parts for scrapping.
- Take plastic parts to be recycled.
- Sort the remaining components by material quality and dispose of them.

1 Product Description

1.1 Characteristics of the TITANUS MICRO·SENS® aspirating smoke detection system

TITANUS MICRO·SENS® is the latest generation of the renowned WAGNER smoke detection systems. The TITANUS MICRO·SENS® can be used for room and equipment protection and for monitoring air conditioning cabinets or air conditioning ducts. Through the innovative ROOM·IDENT process, the system can also locate the site of the fire.

Locating the site of the fire

The unique **ROOM·IDENT** technology makes it possible to determine the location of a fire when monitoring up to 5 separate areas. So that the emergency services can act as quickly as possible, the seat of the fire can be made known, for example, via reaction indicators which are allocated to the various monitoring areas.

Sensitivity

The TITANUS MICRO·SENS® reaction threshold can be set at between 0.1 %/m and 2 %/m light obscuration in steps of 0.1%/m. Using a smoke level indicator, an indicator sensitivity of between 0.05 %/m and 0.2 %/m light obscuration can be achieved. The **HIGH POWER LIGHT SOURCE** light source technology used in TITANUS® systems guarantees homogeneous reaction behaviour from different types of fire. The device can provide 2 alarm thresholds (pre alarm and alarm). The pre-alarm threshold is adjustable from 10 - 80 % of the fire alarm threshold.

Intelligent signal processing

The TITANUS MICRO·SENS® has **LOGIC·SENS** intelligent signal processing for avoiding false alarms. Perfected algorithms based on numerous fire trials and decades of experience ensure a high level of safety in differentiating between a false status and a fire event.

Safe airflow monitoring

PIPE·GUARD, the comprehensive package for airflow monitoring, recognises safe breakdowns such as pipe breakages or blocked detection apertures. Using dynamic airflow monitoring, the TITANUS MICRO·SENS® reacts even to small, quick changes in the airflow and thus makes an important contribution to sabotage safety.

Airflow monitoring is temperature-compensated and can be set to be air pressure-dependent.

Plug and Play	<p>Installation and commissioning of the TITANUS MICRO·SENS® are simple with the Plug & Play function.</p> <p>The device base is pre-assembled on site. By pre-setting the detection unit for standard applications, the TITANUS MICRO·SENS® is operational immediately after it is inserted in the device base.</p>
Redundancy ventilators	<p>For maximum safety, the TITANUS MICRO·SENS® can be fitted with redundancy ventilators as an option. During operation of the device with the redundancy ventilator, ROOM-IDENT is not possible.</p>
Network capacity	<p>Fitted with a network card, several TITANUS MICRO·SENS® devices can be linked together in an Ethernet network. From a central point the user can, for example, via VisuLAN T® monitor the whole plant for smoke levels, airflow values etc. In addition, the TITANUS MICRO·SENS® can be integrated via the so-called OPC server into existing hazard and building management systems.</p>
Potential free contacts	<p>The TITANUS MICRO·SENS® has one potential free contact each for alarm and fault. So the smoke detection system can be switched to collective and addressable¹ recording lines of any central fire alarm systems (FAS). A relay card (optional) can be connected to the TITANUS MICRO·SENS® in order to connect the potential-free contact for the pre-alarm to a detector line of a CFDU.</p>
Diagnostics	<p>With the DIAG 3 diagnostics device, there is a system available for commissioning, inspection and servicing which makes it possible to configure the device quickly and easily and contain faults. For diagnostics purposes events are stored in the TITANUS MICRO·SENS® for 72 hours.</p>
Designing detection points	<p>The monitoring surfaces of the detection point type for the TITANUS MICRO·SENS® are to be set to match the point-specific smoke alarms. The detection points can thus be designed similar to point-specific smoke alarms in accordance with the particular national regulations.</p>
Patented detection points	<p>Wagner's patented detection reducing films, clips and banderols make assembly simple and comfortable and avoid whistling operational noises. An even inflow of air through all the apertures is achieved with a stepped aperture diameter. These are fitted with rapidly checkable identification.</p>
Extensive pipe accessories	<p>Wagner's extensive range of accessories makes it possible to use the TITANUS® aspirating smoke detection system even under the most difficult of conditions. Products from various types of air filter from condensate traps to blow through devices raise the serviceable life under extreme dusty, humid and excessively cold environmental conditions.</p>

¹ Via the address module of the particular FAS.

1.2 Areas of Application

The TITANUS MICRO·SENS® air sampling smoke **detection** system is a fire alarm system for the protection of rooms, equipment and air conditioning ducts.

Principle Air samples for a monitoring area are taken through the draw-off holes in a pipe system and fed to the detection unit.

The principle is particularly suitable for areas in which point type alarms are not used or can only be used to a limited extent.

This involves areas in particular ...

- where is a high risk of fire,
- where high detection sensitivity is required,
- where false alarms must be avoided,
- which are difficult to access and in which it is difficult to mount and/or inspect point type alarms,
- where interrupting operations for inspection and servicing must be avoided,
- which are air conditioned,
- where the height is greater than is allowed for point type alarms,
- where for aesthetic reasons point type alarms are not wanted,
- where there are strong electromagnetic fields,
- which are subjected to high or low temperatures,
- which have a heavy dust load,
- where the fire alarm equipment must be protected against vandalism or sabotage

Room protection The TITANUS MICRO·SENS® is suitable, for example, for monitoring rooms such as, e.g.

- double floors, intermediate ceilings,
- tunnels, ducts, cavities not easily accessible,
- warehouses, deep freeze stores, lift shafts,
- museums, cultural establishments,
- hotel rooms, hospital rooms, offices, prison cells, railway compartments.




Fig.. 1.1: Principle of Room Monitoring with TITANUS MICRO·SENS® Smoke Detection System

**Room monitoring
with air conditioning**

Room monitoring takes place

- in server rooms with air conditioning,
- in ventilation ducts,
- in double floors, intermediate ceilings,
- in IT rooms, E-distribution rooms, transformer cells,
- for air conditioning cabinets (see Fig. 1.2),
- at bypass of air conditioning ducts.




Fig. 1.2: Monitoring options for a circulating air conditioning cabinet or an air conditioning duct (principle representation)

The TITANUS MICRO·SENS® aspirating smoke detection system can also be used for earliest detection of fires in rooms with special air conditioning.

Its high level of sensitivity means goods and equipment can be reliably monitored. The TITANUS MICRO·SENS® is therefore especially suitable for areas of application.

- in which because of concentrated high values early intervention is necessary,
- in which equipment must always be operational,
- in which highly sensitive detection is required (e.g. in areas where, because of built-in filter elements, there is a low level of smoke particles in the air)
- in which there are high rates of air change.

Device protection unventilated and force-ventilated equipment / cabinets such as, e.g.

- distribution cabinets, switching cabinets,
- telephone switching equipment,
- measuring, control and regulation equipment.




Fig. 1.3: Equipment monitoring principle using the TITANUS MICRO·SENS®

2 Technical Description

2.1 System Description

The TITANUS MICRO·SENS® aspirating smoke detection system comprises a detection unit, device base and pipe system.

The most important components of the TITANUS MICRO·SENS® are the sensitive detection unit for picking up smoke aerosols and the aspiration unit with integrated air flow sensor for transporting air samples and for monitoring the pipe system for breaks and blockages.

The pipe system consists essentially of pipe and fittings, in either PVC or ABS plastics.




Fig. 2.1: Overview of the TITANUS MICRO·SENS® smoke detection system

To guarantee safe operation even under the most difficult conditions (e.g. recycling area), there are extensive accessories available such as, e.g., an integrated air filter, various external air filters or the blow through device. In very cold areas, a deep freeze version of the TITANUS MICRO·SENS® can be used. A redundancy ventilator can be used for applications where there are particular safety requirements.

When fitted to monitor several monitoring areas and blind spots, there are reaction indicators for rapid identification of the seat of the fire and an offset parallel display as a status indicator for the detection unit.

2.1.1 Function

Air samples are taken from the area to be monitored via a pipe system with defined aspiration apertures, using the TITANUS MICRO·SENS® aspiration unit and these are sent to the sensitive detection unit (see Fig.2.1).

Locating the site of the fire

It is possible to locate the site of the fire using ROOM-IDENT with an I-pipe design for a maximum 5 rooms or pieces of equipment. The operating principle incorporates four phases:

Phase 1 During operating conditions air samples are taken from the pipes covering the various rooms. The samples are taken via fan to the detector unit and analysed for possible smoke particles.




Fig. 2.2: Phase 1 ROOM-IDENT standard operation

Phase 2 The system will activate an alarm once it has reached an alarm threshold level due to the rise of typical smoke aerosols. If « Fire alarm after ROOM-IDENT » is enabled, then the localisation process will start after an adjustable Action - Alarm threshold. The system will activate an alarm once the localisation is completed.




Fig. 2.3: Phase 2 ROOM-IDENT Earliest fire detection.

- Phase 3** In case alarm or at function « Fire alarm after ROOM·IDENT » once the system has reached the adjustable action the aspiration fan is switched off and a second fan is switched on, blowing out the smoke particles in the opposite direction.




Fig. 2.4: Phase 2 ROOM-IDENT Blow through.

- Phase 4** After the pipe system has been freed from smoke, the airflow is reversed once again and the time it takes for the smoke to reach the detector unit is measured. With this time value the exact location of the smoke source is given and shows which room is affected.




Fig. 2.5: Phase 4 ROOM-IDENT Localisation.

The alarm is indicated on the TITANUS MICRO·SENS® itself, indicated within the monitored area via an optical external alarm indicator. The System with enabled option «Fire alarm after ROOM IDENT » will now activate an alarm.

- Detection** Depending on the reaction sensitivity of the detection unit used (which can be 0.1 %/m to 2 %/m light obscuration or 0.5 %/m to 2 %/m light obscuration), the TITANUS MICRO·SENS® triggers the main alarm once the corresponding light turbidity is reached. The sensitivity can be set in

steps of 0.1 %/m. The alarm is shown on the device via the alarm display and forwarded to a connected fire alarm system (FAS).

By changing the delay time with the diagnosis tool, the forwarding of alarms and faults can be set.

The intelligent **LOGIC-SENS** signal processing device serves to blank out fire-like false alarms and ensures high false alarm safety.

Airflow monitoring An airflow sensor checks the connected pipe system for breaks and blockages.

Depending on the design of the pipe system and the setting on the air-flow sensor, the blockage of just one aspiration aperture can be picked up. The airflow monitoring is **temperature-compensated** and can be made **air pressure-dependent**.

At the end of the adjustable delay time, the fault is shown on the smoke detection system and a corresponding message is forwarded to the central fire alarm point via a contact. The monitoring windows can be adjusted to the environmental conditions.

The principle of the airflow sensor signalling process can be seen in Fig. 2.6 .

Device monitoring The detection unit is monitored for dirt and signal fault. Any fault which occurs is displayed at the TITANUS MICRO-SENS® and can be forwarded to the FAS via a contact.




Fig. 2.6: Example signal pattern in the airflow sensor during faults

Airflow adjustment Airflow adjustment on the TITANUS MICRO-SENS® is fully automatic when the detection unit is inserted in the device base, if previously the Jumper X4 had been changed. This plug & play reduces the time needed for commissioning to a minimum. It is also possible, however, to adjust the airflow using the DIAG 3 diagnosis tool. This means the initialisation phase can be carried out in an air pressure-dependent or air pressure-independent manner.

Resetting through FAS

A fault message is reset via the connected FAS. If whilst the TITANUS MICRO·SENS® is operating an FAS alarm and fault [messages] have to be reset at the same time as the control line, then as an option a reset board¹ can be inserted in a separate housing. The effect is that when there is any short-term switching off of the line voltage, the alarm and fault messages on the TITANUS MICRO·SENS® are automatically reset.

¹ The reset board can only be placed in a separate housing and if the idle current on the line is between 5 mA and 50 mA. The line must be switched to dead for resetting.

2.2 TITANUS MICRO-SENS® and Accessories

2.2.1 Overview




Fig. 2.7: Overview TITANUS MICRO-SENS®

The components shown in Fig. 2.7 can be used by way of option.

2.2.2 TITANUS MICRO-SENS® air sampling smoke detection system

The TITANUS MICRO-SENS® air sampling smoke detection system comprises the following components, device base, detection unit and pipe system:

Device base

- Connections for 25 mm aspiration pipe (in and return)
- Cable feeds
- Floating contacts for connection to a FAS

Detection unit

- Sensitive detection using the latest technology according to the principle of optical scattered light indicators with integrated airflow monitoring
- Aspiration unit with improved air feed
- Optical displays for smoke levels, main alarm, action alarm, fault, operation and indication of the location of the seat of fire
- Infrared interface for diagnostics




Fig. 2.8: TITANUS® displays and connections (For explanation see table on next page)




Fig. 2.9: TITANUS® display variant with smoke levels and fire location (For explanation see number 1 in table on next page)

TITANUS MICRO·SENS®

Number in Fig. 2.8	Function	Explanation
1	Displays (see to Fig. 2.8 Fig. 2.9)	
	* Smoke level display 1 to 10 (10 yellow LEDs)	Current smoke level
	Operation (green LED)	Operation display
	Fire alarm (red LED)	Smoke level (where main alarm threshold is set)
	Action alarm (red LED)	Smoke level (Value as per main alarm threshold 10 – 80 % adjustable)
	Fault (yellow LED)	Pipe system fault or ventilator breakdown or detector module fault
	* Locating the seat of the fire A – E (5 red LEDs)	Locating the seat of fire
	Infrared interface	Commissioning and fault diagnosis
2	Air sampling pipe connection	for Ø 25 mm pipe system
3	Cable feed, fire alarm cable for switching on FAS and/or power supply (in / out)	2 x M 25
4	Air return pipe connection	for air return
5	Cable feed fire alarm cable	8 x M 20
6	Cable entries (small)	2 x M 20 for cable with Ø of 1 to 13 mm
7	Cable entries (large)	1 x M 25 for cable with Ø of 1 to 18 mm

* optional

2.2.3 Detector Box

External detector boxes can be used in the pipe system in connection with the TITANUS MICRO·SENS® smoke detection system.

Use The detector box is used ...

- to create a two-detector or two-line dependency,
- to be able to locate the branch affected by smoke in multi-branch pipe systems and/or
- to raise the reaction sensitivity in multi-branch pipe systems




Fig. 2.10: TITANUS MICRO·SENS® function principle with detector box for two-detector or two-line dependency




Fig. 2.11: TITANUS MICRO·SENS® function principle with detector box for locating and raising reaction sensitivity

The TITANUS MICRO·SENS® detector box comprises the following components:

Device base

- Connections for 25 mm aspiration pipe (in and out)
- Cable feeds
- Potential-free contacts for connection to a FAS

Detection unit

- Sensitive detection with the latest technology according to the principle of optical scattered light detectors
- Optical displays for smoke level, main alarm, action alarm, fault, operation
- Infrared interface for diagnostics




Fig. 2.12: Detector box displays and connections (For explanation see table, next page)




Fig. 2.13: Display variant, detector box with smoke level (For explanation see number 1 in table)

Detector box

Number in Fig. 2.15	Function	Explanation
1	Displays	
	* Smoke level display 1 to 10 (10 yellow LED's)	Current smoke level
	Operation (green LED)	Operation display
	Fire alarm (red LED)	Smoke level (where main alarm threshold is set)
	Action alarm (red LED)	Smoke level (Value as per main alarm threshold 10 – 80 % adjustable)
	Fault (yellow LED)	Pipe system fault or ventilator breakdown or detector module fault
	Infrared interface	Commissioning and fault diagnosis
2	Air sampling pipe connection	for Ø 25 mm pipe system
3	Cable feed, fire alarm cable for switching on FAS and/or power supply (in / out)	2 x M 25
4	Cable feed fire alarm cable	8 x M 20
5	Cable entries (small)	2 x M 20 for cable with Ø of 1 to 13 mm
6	Cable entries (large)	1 x M 25 for cable with Ø of 1 to 18 mm

* optional

2.2.4 Diagnostics tool




Fig. 2.14: Diagnostics tool for inputting and reading off device data

Using the DIAG 3 diagnosis tool, the device configuration for the TITANUS MICRO·SENS® can be changed during commissioning. For maintenance and servicing, there is the option with the diagnosis software to display the stored and current device status and error messages from the TITANUS MICRO·SENS® on a PC or laptop. For the data transfer to the diagnostics equipment the infrared interface of the TITANUS MICRO·SENS® is used. There is a USB cable for transferring data from the diagnostics equipment to the PC/laptop connection.



TIP

It is recommended that the commissioning status are read out, checked and recorded.

Diagnosis messages can be deleted at any time using the DIAG 3 diagnosis tool. If they are not deleted, the messages are stored in the TITANUS MICRO·SENS® for 72 hours. This allows for evaluation of short, sporadic faults (e.g. in changed operating conditions).

2.2.5 Parallel Displays




Fig. 2.15: Parallel display for wall mounting

The TITANUS MICRO·SENS® offers the possibility of connecting one or more parallel displays. The displays on the parallel display are identical to those on the detection unit. The connection is made in the TITANUS MICRO·SENS® device base.

A parallel display can be connected up to a distance of **1000 m**. If a second parallel display [sic] is connected behind the first one, this can in turn again be **1000 m** from the first one. This is possible as each parallel display is also a repeater.

The power supply for small distances is direct through TITANUS MICRO·SENS®, and for longer distances via an external supply (see Chapter 4.4 "Power Supply Calculation").

2.2.6 Reaction Indicator




Fig. 2.16: Reaction indicator for locating the site of a fire

When the TITANUS MICRO·SENS® is used with fire location, up to 5 addressable reaction indicators can be used via the indicator bus.

The reaction indicator can be connected up to a distance of 1000 m.

2.3 Pipe system

2.3.1 Overview




Fig. 2.21: Components of the pipe system for smoke detection systems

The accessory components shown in Fig. 2.21 are to be chosen for the particular individual case and can be used in combination.

Free blow device

In areas in which there is expected to be an increased occurrence of dust particles or ice formation, blowing through of the aspiration pipe system and aspiration apertures may be necessary. Fig. 2.22 and Fig. 2.23 each show the components of a manual and an automatic blowing-out system. Depending on the frequency of blockages, the blow-through process can be undertaken manually or automatically.




Fig. 2.22: Components of the manual blowing-out system




Fig. 2.23: Components of the automatic blowing-out system

2.3.2 Aspiration apertures for room monitoring

2.3.2.1 Aspiration reduction films




Fig. 2.24: Aspiration aperture with aspiration reduction film and banderol

An aspiration aperture is a 10 mm hole in the aspiration pipe which is covered by a patented aspiration reduction film with the required aperture diameter. The size of the aperture depends on the pipe system design (see Chapter 4, "Design").

To prevent the aspiration reduction film coming loose, it is held in place by a banderol. The banderol is a transparent adhesive film with red edges and a 10 mm large hole. It is stuck over the aspiration reduction film in such a way that the aspiration aperture is not covered and is also visible at larger distances.

The standard type AF-x aspiration reduction films and the type AF-BR banderol's are not suitable for use in very low temperature areas. Aspiration reduction clips are to be used in these areas instead (see Chapter 2.3.2.2).

2.3.2.2 Aspiration reduction clips




Fig. 2.25: Aspiration reduction for dirty areas and deep freeze areas

The aspiration apertures used in areas where there may be blockages are fitted with a patented type AK-C plastic clip and a patented type AK-x flexible aspiration reduction (see Fig. 2.25). The aspiration reducers are available in defined, stepped aperture diameters.

With blowing through, the flexible aspiration reducer stretches to the aspiration apertures. In deep freeze areas this leads to icing breaking off and in very dusty areas to dirt breaking off. The special plastic clip is for fixing the aspiration reduction to the pre-defined point.

When designing for areas with environmental influences which make blowing through necessary (e.g. dust) or very humid areas, the aspiration reducers with a plastic clip are to be preferred over aspiration reduction films with banderol. The plastic clips have greater resistance when subject to pressure stress. There is also a greater cleaning effect thanks to the elastic rubber insert.

2.3.3 Ceiling duct for concealed mounting




Fig. 2.26: Ceiling duct for intermediate ceilings

Aesthetics

If room monitoring requires a concealed pipe system installation, then it can be mounted in an intermediate ceiling. Ceiling ducts into the intermediate ceiling are then used. The ceiling ducts are – in accordance with design guidelines – fitted with aspiration reduction films with defined aspiration apertures (see Chapter 4 "Design"). The ceiling ducts are then connected to the pipe system via aspiration hoses (see Fig. 2.26).

If the length of these hoses is a maximum 3 m, then the design according to Chapter 4 applies. If because of building circumstances lengths of more than 3 m are required, the pipe system must be calculated³.

The ceiling duct can be used for intermediate ceiling boards up to about 35 mm in strength. The aspiration reduction films are available in two colours (pure white, RAL 9010 and papyrus white, RAL 9018) and also in special colours on request.

³ The calculation is worked out by WAGNER

2.3.4 Air filters for dusty areas




Fig. 2.27: TITANUS MICRO-SENS® with air filter

In areas with interference to the environment such as, e.g. dust, an air filter is to be used to protect the smoke detection system.

Type LF-AD-x air filter

The standard air filter used is the type LF-AD-x, comprising a plastic housing with two PG29 threaded connections. The multi-layer filter material absorbs particles which are larger than about 15 µm.

The air filter is automatically monitored for dirt (blockage) by the TITANUS MICRO-SENS® air flow monitoring arrangement. If the air filters are dirty, then the filter inserts must be changed by opening the filter housing.

Special type SF-x filter

In extremely dusty areas (e.g. recycling plants) in which the use of an LF-AD is not sufficient, a special filter must be used. The special filter safely holds back the dust particles in a heavily polluted atmosphere using the filter medium. The filter is guaranteed to have an even quality of dust collection right through to the end of its useful life. Two types of special filter are available (type SF-400 and type SF-650), the SF-650 having a longer useful life because of its larger surface area.

2.3.5 Air return for pressure differences and air pollution




Fig. 2.28: Principle of air return in the TITANUS MICRO·SENS®

If the TITANUS MICRO·SENS® and the pipe system are installed in two areas P1 and P2 with different air pressures, the air drawn off has to be returned to the pipe system pressure range (see Fig. 2.28). Returning the air can also avoid air pollution (e.g. smells) in neighbouring rooms.




Fig. 2.29: TITANUS MICRO·SENS® with air return

The air return pipe is mounted in the conical pipe plug-in connection for the TITANUS MICRO·SENS® air return (see Fig. 2.29). As the air return pipe sits perfectly in the air return pipe, a firm hold is guaranteed.

2.3.6 Noise suppressor




Fig. 2.30: TITANUS® with noise suppressor

By using the SD-1 noise suppressor, the noise level can be reduced by up to 10 db(A) for use in areas in which low noise emissions are required from the TITANUS® (such as in offices or hospitals).

The noise suppressor is mounted directly to the air recirculation on the TITANUS®.

2.3.7 Steam trap for humid areas




Fig. 2.31: Steam trap to eliminate water vapour from the pipe system and to collect the condensate from the pipe system

If the TITANUS MICRO·SENS® is operated in environments where condensate can form in the pipe system, then a condensate trap is used. To collect the condensate, the steam trap is fitted at the lowest point of the pipe system, between the air filter and the smoke detection system. Using 45° angles gives optimum wall distance.

The steam trap can be operated in a temperature range of 0°C to +50°C. The sinter filter in the condensate trap has a pore width of 50 µm and additionally absorbs coarse dust particles.

The condensate trap is used in the following areas:

Areas of application

- Areas with severely oscillating temperatures and high air humidity
- External areas
- Sauna areas

3 Technical Data



All power consumption figures relate to an ambient temperature of 20°C.

3.1 TITANUS MICRO·SENS®

	TITANUS MICRO·SENS®				
Voltage	Power supply (Ue) Nominal power supply	16 to 30 V DC 24 V DC			
Current		U _L ¹ = 9 V (at 24 V)	U _L = 10.5V (at 24 V)	U _L = 12 V (at 24 V)	U _L = 13.5V (at 24 V)
	Starting current ²	150 mA			
	Power consumption at idle status ²	105 mA	125 mA	145 mA	170 mA
	Power consumption at alarm status ² Device variant with fire alarm	110 mA	130 mA	150 mA	175 mA
	Power consumption at alarm status ² fire alarm, smoke level	140 mA	160 mA	180 mA	205 mA
Outputs	Contact loading capacity of the alarm and fault relay	1A / 30VDC			
Dimension	Dimensions (H x W x D mm)	70 x 140 x 222 mm			
Weight	Weight	0.8 kg			
Sound intensity level	L _{wa} as per EN 27779, 1991	40 dB(A) at 9V			
Protection class	Protection class (EN 60 529) without air return with pipe piece 100 mm/pipe bend with air return	IP 20 IP 42 IP 54			

¹ U_L = Ventilator voltage

² without extra module

		TITANUS MICRO·SENS®
Housing	Material	Plastic (ABS)
	Colour Housing	papyrus white, RAL 9018
Temperature range	TITANUS MICRO·SENS® Deep freeze version	– 20° to +60° C – 40° to +60° C
Humidity	not condensed	max. 95 % rf (without dew)
Ventilator	Type of construction	axial
	Lifetime of ventilator (12V)	60.000 h at 24° C
Displays on device	Operation	green operating display
	Fire alarm	red alarm display
	Action alarm	red alarm display (optional)
	Fault	yellow collective fault
	Smoke level display	yellow smoke level display 1 to 10 (10 segments) (optional)
	Alarm location display	5 red displays (optional)
Infrared interface	Infrared interface	IR Transmitter/ Receiver
Connections	Device connection	Clips for 0.5 – 2.5 mm² wires
	Cable	pair twisted,
	Cable feeds device base	8 x M 20 2 x M 25
	Device base floor	4 x M 25
	conical pipe plug-in connections	1 x for aspiration pipe Ø 25 mm and 1x air return Ø 25 mm
Reaction sensitivity	Detection unit	
	DM-TM-10	0.1 to 2.0 % light obscuration/m
	DM-TM-50	0.5 to 2.0 % light obscuration/m

3.2 TITANUS MICRO·SENS® detection box

		Detection box
Voltage	Power supply (U _e) Nominal power supply	15 to 30 V DC 24 V DC
with Bargraph and Processor	Power consumption at idle status	30 mA
	Power consumption at alarm status fire alarm	38 mA
	Power consumption at alarm status fire alarm, smoke level	68 mA
Dimension	Dimensions (H x W x D mm)	70 x 140 x 222 mm
Weight	Weight	0.8 kg
Protection class	Protection class (EN 60 529)	IP 54
Housing	Material	Plastic (ABS)
	Colour Housing	papyrus white, RAL 9018
Temperature range	Detection box	– 20° to +60°C
	Deep freeze version	– 40° to +60°C
Humidity	not condensed	max. 95 % rf (without dew)
Displays on device	Operation	green operating display
	Fire alarm	red alarm display
	Action alarm	red alarm display (optional)
	Fault	yellow collective fault
	Smoke level display	yellow smoke level display 1 to 10 (10 segments) (optional)
Infrared interface	Infrared interface	IR Transmitter / Receiver
Connections	Device connection	Clips for 0.5 – 2.5 mm ² wires
	Cable	pair twisted,
	Cable feeds	
	Detection box base	8 x M 20 2 x M 25
	Detection box base floor	4 x M 25
	conical pipe plug-in connections	2 x for pipe Ø 25 mm
Reaction sensitivity	Detection unit	
	DM-TM-10	0.1 to 2.0 % light obscuration/m
	DM-TM-50	0.5 to 2.0 % light obscuration/m

3.3 Accessories – TITANUS MICRO·SENS®

		Parallel display for TITANUS MICRO·SENS®
Parallel display	Voltage Nominal voltage	24V
	Power consumption (at 24 V) idle maximum	15 mA 50 mA
	electr. connection lengths	max. 1000 m
Dimension	Dimensions (H x W x D mm)	70 x 140 x 200 mm
Weight	Weight	0.6 kg
Protection class	Protection class (EN 60 529)	IP 54
Housing	Material	Plastic (ABS)
	Colour Housing	papyrus white, RAL 9018
Temperature range	Parallel display	– 20° to +60°C
Displays on device	Operation	green operating display
	Fire alarm	red alarm display
	Action alarm	red alarm display (optional)
	Fault	yellow collective fault
	Smoke level display	yellow smoke level display 1 to 10 (10 segments) (optional)
	Alarm location display	5 red displays (optional)
Connections	Clip strip	Clips for max. 2.5 mm² wires
	Cable	pair twisted,
Cable feeds	Parallel display base	8 x M 20 2 x M 25
	Parallel display base floor	4 x M 25

Reaction indicator

Voltage Nominal voltage	15 to 30 V DC 24 V DC
Power consumption (at 24 V)	
Stand by	2 mA
Blink light	5 mA
Steady burning	8 mA
electr. connection lengths	1000 m
Protection class (EN 60 529)	IP 30

**Relay board
RU-1/RU-2**

Dimensions	98 x 94 mm
Temperature range	-40 °C to +60 °C
Contact loading capacity of the relay contacts	1 A to 30 V DC
Power consumption (at 24 V)	
RU-1	
idle status	6 mA
alarm status	max. 36 mA
RU-2	
idle status	13 mA
alarm status	max. 36 mA

Reset board

Power consumption	max. 20 mA
-------------------	------------

Network module

Power consumption	max. 40 mA
-------------------	------------

3.4 Pipe System – TITANUS MICRO·SENS®

Pipe system		Pipe system for TITANUS MICRO·SENS®
	max. pipe length Ø 25 mm	50 m
	plus max. pipe length Ø 12 mm	8 x 3 m
	max. no. aspiration apertures	8
	max. length aspiration hose per ceiling duct	3 m
	Temperature range PVC pipe ABS pipe	0°C..+60° C -40°C..+80° C
	max. monitoring surface area	400 m ²

4 Design

4.1 General

The following describes the project planning of the air sampling smoke detection system to EN 54-20. The basic conditions are described in Chapter 4.1. The project planning is to be conducted in accordance with Chapter 4.2.

The limiting project planning instructions in accordance with Chapter 4.2 apply to special applications in addition to Chapter 4.3. These should be taken into consideration at the beginning of project planning for special projects.

Project planning options according to EN 54-20:

There are various technical solutions to be selected from, depending on the project planning criteria. The chapters for the solutions are listed in the following tables.

Project planning criterion	Technical solution	Basic Principles	Limitations
General area monitoring	Standard project planning	Chapter 4.2	---
Recognition of a failure at an individual aperture	Project planning for individual aperture monitoring	Chapter 4.2	Chapter 4.3.1
Device protection/cabinet monitoring	Simplified pipe project planning	Chapter 4.2	Chapter 4.3.2
Ventilation conduits	Project planning for forced air flow	Chapter 4.2	Chapter 4.3.5

4.1.1 Regulations

The current respective national regulations in each particular country must also be complied with and project planning must be adjusted to such regulations.

EN 54-20

The air sampling smoke detection systems shall be planned in accordance with the project planning guidelines described in Chapter 4.2.1 in order to be compliant with EN 54-20.

The following guidelines must also be complied with for systems in accordance with the requirements of VdS Schadenverhütung:

- "Guideline for automatic fire alarm systems, planning and installation", VdS Schadenverhütung GmbH, Cologne, Germany (VdS 2095)
- "Local application protection for electric and electronic equipment - rules for planning and installation" guideline, VdS Schadenverhütung GmbH, Cologne, Germany (VdS 2304)
- The technical bulletin "Project Planning for air sampling fire alarms" VdS Schadenverhütung GmbH, Cologne, Germany (VdS 3435)

The following national regulations must also be complied with in Germany, for instance:

- DIN VDE 0833 part 1 and 2 "Alarm systems for fire, intrusion und hold-up"
- Additional regulations for installing fire alarm systems which are laid down by fire authorities and building supervisory boards or building regulation authorities and are only valid locally.

4.1.2 Pipe system

When planning the pipe system, it must be ensured that reliable fire detection is guaranteed for any fire present in an installation or in a monitored area. Fig. 4.1 depicts an example of a U-pipe system with symmetrical or asymmetrical design and the diameters of the aspiration apertures calculated according to Chapter 4.6.2 "Standard planning."

The number of the intake apertures and the pipe system design depends on the size, ventilation and shape of the monitored area. The aspiration apertures should be planned like point-type detectors. The pipe system is to be fitted in accordance with the project planning guidelines in this section while taking the following points into consideration:

Symmetrical design The pipe system should preferably have a symmetrical design, i.e.:

- equal number of aspiration apertures per pipeline branch
- equal lengths of pipeline (must not exceed $\pm 20\%$ deviation)
- equal distance between neighbouring aspiration apertures on the smoke aspiration pipe (must not exceed $\pm 20\%$ deviation)

Asymmetrical design The following specifications apply in the event that pipe system must be laid out asymmetrical due to structural conditions (see also Fig. 4.1):

- The number of aspiration apertures as well as the length of the shortest and longest pipeline branch in the pipe system must not exceed a quantity or length ratio of **1:2**.
- The distances between adjacent aspiration apertures in the sampling pipe must be identical (should not exceed deviation of $\pm 20\%$).
- The diameters of the aspiration apertures are determined for each pipeline branch individually and depend on the number of aspiration apertures on the pipeline branch in question. The commensurate aperture diameters can be found in the tables in Chap. 4.2.4.




Fig. 4.1: Example of a symmetrical and an asymmetrical U-pipe system

Branch length In order to ensure a short transport time for the smoke fumes in the sampling pipe and thus enable rapid detection, it is better to plan several shorter than a few long ones (preferably a U- or double U-pipe system).

Pipe designs 4 types of pipe designs can be selected, depending on the cabinet geometry (see Figure 4.2).

I- pipe An air sampling smoke detection pipe system without branches.

U- pipe An air sampling smoke detection pipe system which branches into 2 air sampling branches after the connection to the TITANUS MICRO·SENS®.

M-pipe An air sampling smoke detection pipe system which branches into 3 air sampling branches after the connection to the TITANUS MICRO·SENS®.

Double U-pipe An air sampling smoke detection pipe system which branches into 4 air sampling branches after the connection to the TITANUS MICRO·SENS®.



The design for fire location should be the I-pipe configuration.




Fig. 4.2: Pipe designs

Direction change

Angles and bends in the pipe system increase flow resistance. For that reason, it is necessary to limit the number of them to the amount required.

It is preferable to use bends, since angles have a higher flow resistance. Angles should therefore only be used where they are necessary due to structural constraints.

	Corresponds to a straight pipe length of
Angle	1.5m
Bend	0.3m

If the pipe system includes angles or bends, the maximum overall length of the pipe system will be reduced.



Bends are to be preferred over angles.
An excessive number of changes in direction can change the detection time.

Special cases If the pipe system does not match the project planning guidelines described here due to structural constraints, WAGNER should make the individual calculations for such a case.

Checking Check detection reliability with activation tests in cases where use of the system is critical. Also check whether an air flow rate is present at individual aspiration apertures.



The fan voltage can be increased in order to reduce transport time.
Make sure that the current intake increases.

4.1.3 Air flow monitoring

EN 54-20 requires the recognition of a 20 percent change in the air flow volume by the detector module's air flow sensor system. The activating threshold of the air flow sensor system has to be adjusted to $\leq 20\%$ in order to achieve this. It is recommended to conduct an air pressure-dependent air flow compensation for both of these settings.

Any threshold desired may be set with systems which do not require EN 54-20 conformity.

Project planning for the air flow monitoring system in sampling pipes is carried out while taking into consideration the respective national regulations for each country.

Adjusting the air flow sensitivity

The air flow sensor sensitivity must be adjusted to the application in question. Breakage and stoppages must be detected reliably with low susceptibility to malfunction.

The activating threshold and for this reason the sensitivity of the air flow sensor is continuously adjustable from 10 – 50 %.

	In conformity with EN 54-20			
Triggering threshold	10 %	20 %	40 %	50 %
Sensitivity	Very high	High	Medium	Low



TIP

It is recommended to always select the greatest possible level which is permissible according to national standards.

Dynamic air flow sensor system

The device's air flow monitoring enables the system to detect both pipe breakages outside the device and sudden obstruction in individual aspiration apertures (e.g. in the event of sabotage to the pipe system). The dynamic air flow sensor system has been activated via the diagnostics software, the following modifications have to be regarded.

Limitations The air flow monitoring may only be set, if:

- Project planning according to “Individual aperture monitoring” has been carried out (see Chap. 4.3.1 “Pipe project planning individual aperture monitoring”),
- the air flow sensor has been compensated depending on the air pressure (see Chap. 7.1.2 “Air pressure dependent air flow compensation”) and
- No large air flow fluctuations occur.

Air pressure differences The same air pressure must be present throughout the sampling pipe.



If the air sampling smoke detection system and pipe system are in areas with different air pressure, the air sampled by the TITANUS MICRO-SENS® should be re-circulated in the pipe system pressure area (see Chapter 2.3.5 “Air recirculation”).



TITANUS MICRO-SENS® with active location of the fire must be installed outside the areas to be monitored and without air return.



ROOM IDENT cannot be used in applications with varying or not consistent air pressure levels. This is due to the fact, that under these conditions the aspirated air needs to be returned to the monitored area. Since air return is not allowed with ROOM-IDENT these applications cannot be served.

4.1.4 Sensitivity

According to EN 54-20, the sensitivity of a air sampling smoke detection system can be divided into particular fire sensitivity classes. These sensitivity classes describe particular example applications in which the systems can be used. Permissible system project planning can be determined for each classification according to Chapter 4.2.

Air sampling smoke detection systems with a higher sensitivity class according to EN 54-20 also meet the requirements of the lower classes.

Class	Description	Example application
A	Air sampling smoke detector with very high sensitivity	Very early detection: Highly diluted smoke in air conditioned IT areas
B	Air sampling smoke detector with increased sensitivity	Early detection: Diluted smoke in conventional cooled IT areas.
C	Air sampling smoke detector with standard sensitivity	Standard detection: Fire detection with the benefits of air sampling smoke detection systems



The fire sensitivity classes A, B and C can be achieved with each detection unit available, depending on the number of aspiration apertures.

The following sensitivities can be adjusted with the different detection units.

	sensitivity	sensitivity Standard	adjustment levels
detection unit DM-TM-10	0,1 - 2 % /m	0,1 % /m	0,1 % /m
detection unit DM-TM-50	0,5 - 2 % /m	0,5 % /m	0,1 % /m

Project planning for the monitored surface is always carried out according to national specifications for point-shaped smoke detectors.

4.1.5 Design Limits

The following limit values must always be observed with the TITANUS MICRO·SENS®:

- The minimum pipe length between 2 aspiration apertures is **0.1 m**.
- The minimum pipe length between 2 aspiration apertures when locating a fire is **3 m**.
- The maximum pipe length between 2 aspiration apertures is **10 m**.
- The maximum monitoring surface area per aspiration aperture corresponds to the monitoring area of a point-specific alarm according to the regulations in the particular national standards.
- Maximum 8 aspiration apertures are possible¹.
- Maximum 5 aspiration apertures are possible with site of a fire location.

The maximum overall monitoring surface area for the TITANUS MICRO·SENS® and the maximum overall pipe length depend on the design chosen.

max. overall monitoring surface area per TITANUS MICRO · SENS®	max. design pipe length ²
400 m ²	Pipe Ø 25 mm: 50 m plus Pipe Ø12 mm: 8 x 3 m



Because of country-specific regulations, there may be restrictions compared to the design limits in the manual!

¹ Designs / design forms not given in the manual are to be requested.

² Depending on the design chosen, restricted values apply in part.

4.2 Project planning

4.2.1 Project planning guidelines

In order to conduct project planning in accordance with the EN 54-20 standard, it is necessary to be familiar with particular factors. These are the requirements for the system's sensitivity, the number of aspiration apertures and the accessories necessary for the corresponding application. The pipe system design in conformity with the standard can be determined based on these factors using the following chapter and with the help of the project planning tables in the appendix.

4.2.1.1 Determining the necessary accessories

Since the accessory components, such as filters, have a certain influence on the dimension of the pipe planning, the suitable accessories must be selected for the corresponding application ahead of time. Retrofitting, with a fine filter, for instance, is generally only possible if a more sensitive detector module is being used or a particular reserve has been planned in advance.



Components which have not been approved by WAGNER are used, CE conformity on the basis of EN 54-20 will not be possible.

The following accessory components should be taken into consideration in the process:

- Air filters
- Steam trap
- VSK stop valves
- Detector box
- OXY·SENS® air sampling detector

The SD-1 noise suppressor may be used in any case with no project planning restrictions.

4.2.2 Pipe accessories

Air filters

Type	Application	Examples
LF-AD	Coarse filter for separating particles > approx. 15 µm	Dust, insects, fibres, hair, cinders, pollen
LF-AD-1	Filter for separating particles > approx. 10 µm	As above. Additionally: Colour pigments and fine dust
LF-AD-2	Fine filter for separating particles > approx. 5 µm	As above. Additionally: Fine dust in low concentrations
SF-400	Fine filter for separating particles > approx. 1 µm	As above. Additionally: Fine dust in high concentrations
SF-650	Fine filter for separating particles > approx. 1 µm	As above, but with increased filter lifetime

Steam trap

Type	Application
KA-DN-25	Condensation separator for applications with condensation moisture in the pipe

Sound suppressor

Type	Application
SD-1	Sound suppressor for areas sensitive to noise

Stop valve

Type	Application
AVK-PV	Stop valve for VSK cleaning air nozzle
AVK-PV-F	Stop valve for VSK cleaning air nozzle for use in freezer areas

4.2.3 Sensitivity and pipeline project planning

4.2.3.1 Pipeline project planning with pipe accessories

The following project planning tables for pipeline project planning can be found in the appendix for each previously selected pipe accessory.

- Project planning without filter
- Project planning with LF-AD air filter
- Project planning with LF-AD-1 air filter
- Project planning with LF-AD-2 air filter
- Project planning with SF-400 / SF-650 air filter



An area can be monitored with more than detection points than required by the national guideline in order to improve an air sampling smoke detection system's detection quality. In such case, the number of normatively required sampling points is to be used in calculating the required sensitivity of an air sampling smoke detection system.

Procedure In the following example, a project plan is supposed to fulfil class B requirements with air filters LF-AD-1, with 4 apertures and without further accessory. The red arrows show the possible project plans with varying pipe shapes and fan voltages.

1.	<u>Selection</u> Selection of the corresponding project planning table based on the air filter to be used (see Chap. 4.2.2)
	<u>Result</u> The project planning table has been determined
2.	<u>Selection</u> Selection of the number of aspiration apertures in the project planning table
	<u>Result</u> The achievable sensitivity class for the selected number of apertures has been determined
3.	<u>Selection</u> Determinations on the sensitivity necessary to achieve the sensitivity class
	<u>Result</u> Determination of the detection unit and sensitivity setting
4.	<u>Selection</u> Selection of other pipe components (e.g. steam trap see Chap. 4.2.2 described components)
	<u>Result</u> The project planning table has been determined
5.	<u>Selection</u> Pipe length selection
	<u>Result</u> Determination of the pipe shape and necessary fan voltage.

1 Projection with filter LF-AD-1

Type	Sensitivity (% obs/m)	Number of apertures							
		1	2	3	4	5	6	7	8
DM-TM-10	0,1	A	A	A	A	A	A	A	A
	0,2	A	A	A	A	B	B	B	B
	0,3	A	A	A	B	B	B	B	B
	0,4	A	A	B	B	B	B	C	C
DM-TM-50	0,5	A	B	B	B	C	C	C	C
	0,6	A	B	B	B	C	C	C	C
	0,7	A	B	B	C	C	C	C	C
	0,8	A	B	B	C	C	C	C	C
	0,9	A	B	C	C	C	C	C	C
	1	B	B	C	C	C	C	C	
	1,1	B	B	C	C	C	C	C	
	1,2	B	B	C	C	C	C		
	1,3	B	C	C	C	C	C		
	1,4	B	C	C	C	C			
	1,5	B	C	C	C	C			
	1,6	B	C	C	C				
	1,7	B	C	C	C				
	1,8	B	C	C	C				
	1,9	B	C	C	C				
	2	B	C	C					

without additional pipe accessories or with detector box DM-MB-T-M-XX

Pipe shape	U _{Fan} [V]	1	2	3	4	5	6	7	8	permitted total pipe length [m]
I	≥9	40	40	40	40	40				
U	≥9	50	50	50	50	50	50	50	50	
M	≥9	50	50	50	50	50	50	50	50	
Double U	≥9	50	50	50	50	50	50	50	50	

with steam trap

Pipe shape	U _{Fan} [V]	1	2	3	4	5	6	7	8	permitted total pipe length [m]
I	≥9	40	40	40						
U	≥9	50	50	50	50	50	50			
M	≥9	50	50	50	50	50	50			
Double U	≥9	50	50	50	50	50	50	50	50	

Results: The following modules may optionally be used with the corresponding settings for class B or A:

- Detection unit DM-TM-10 – with a sensitivity of 0,1 % LT/m to 0,6 % LT/m
- Detection unit DM-TM-50 – with a sensitivity of 0,5 % LT/m to 0,6 % LT/m

Possible system parameters:

- I- pipe system
 - ≥ 9 V fan voltage, max. 40 m overall pipe length
- U- pipe system
 - ≥ 9 V fan voltage, max. 50 m overall pipe length
- M- pipe system,
 - ≥ 9 V fan voltage, max. 50 m overall pipe length
- Double U- pipe system,
 - ≥ 9 V fan voltage, max. 50 m overall pipe length

4.2.4 Aperture diameter

The aperture diameters of the aspiration apertures can be found in the corresponding table for the respective pipe configuration:

I-Pipe




Fig. 4.3: I-Pipe system

Aspiration apertures

Number of apertures	1	2	3	4	5
Sampling aperture \varnothing in mm ³⁾					
A	6.8	5.0	4.2	3.4	3.0
B	—	5.0	4.2	3.6	3.2
C	—	—	4.4	3.8	3.4
D	—	—	—	4.4	3.6
E	—	—	—	—	4.4

U-Pipe




Fig. 4.4: U-Pipe system

Aspiration apertures

Number of apertures	2	4	6	8
Sampling aperture \varnothing in mm ³⁾				
A	6.0	4.2	3.4	3.0
B	—	4.6	3.6	3.0
C	—	—	4.4	3.6
D	—	—	—	4.0

³⁾ Press cut diameter in aspiration-reducing film sheet

M-Pipe




Fig. 4.5: M –Pipe system

Aspiration apertures

Number of apertures	3	6
Sampling aperture \varnothing in mm ⁴⁾		
A	5.0	3.6
B	—	4.0

Double-U-Pipe




Fig. 4.6: Double -U –Pipe system

Aspiration apertures

Number of apertures	4	8
Sampling aperture \varnothing in mm ⁴⁾		
A	4.4	3.0
B	—	3.8

⁴⁾ Press cut diameter in aspiration-reducing film sheet

4.3 Special project planning

4.3.1 Project planning for individual aperture monitoring

The following system parameters apply to the detection of an individual or a particular number of blocked aspiration apertures, depending on pipe configuration.

The specifications according to Chapter 4.2 apply to project planning. The following limit values and aperture diameters should also be taken into account. Additional accessories (air filters, condensation separators, etc.) can influence the maximum pipe length.

4.3.1.1 I-Pipe system

1 Pipe system

**TITANUS
MICRO·SENS®**




Fig. 4.7: I-Pipe system for area protection

Limit values

min. distance TITANUS® – 1 st aspiration aperture	2 m
max. distance TITANUS® – 1 st aspiration aperture	20 m
max. overall pipe length per pipe system pipe Ø 25 mm plus pipe Ø 12 mm	40 m 5 x 3 m
max. overall pipe length per pipe system with a ventilator voltage <10.5 V pipe Ø 25 mm plus pipe Ø 12 mm	30 m 5 x 3m
min. distance between 2 aspiration apertures (d)	4 m
max. distance between 2 aspiration apertures (d)	10 m
max. number aspiration apertures (n) per pipe system	5 no.

Aspiration apertures

Number of apertures per pipe system	1	2	3	4	5
Ø Aspiration aperture in mm ⁵⁾					
A	6,8	4,6	4,0	3,4	3,0
B	—	5,0	4,2	3,6	3,2
C	—	—	4,4	3,8	3,4
D	—	—	—	4,0	3,6
E	—	—	—	—	3,8

Trigger Thresholds I-Pipe system

Trigger threshold

Number of apertures	2	3	4	5
1 blocked aperture	± 30 %	± 20 %	± 15 %	± 10 %
2 blocked apertures	○ ⁶⁾	○	± 30 %	± 20 %
3 blocked apertures	○	○	○	○
4 blocked apertures	○	○	○	○
5 blocked apertures	○	○	○	○
... is/are recognised when main air flow set x %				

Example

If the blockage of **2** aspiration apertures out of a total of **5** aspiration apertures is recognised, then with the help of the diagnosis tool flow monitoring can be set to **± 20 %**.



For a project planning according to EN 54-20, the air flow monitoring has to be adjusted to ≤ 20 % in either case.

⁵⁾ Opening diameter of the aspiration reducing film

⁶⁾ ○ not sensible

4.3.1.2 U-Pipe system

1 Pipe system

**TITANUS
MICRO·SENS®**




Fig. 4.6: U-Pipe system for area protection

Limit values

min. distance TITANUS® – T piece	2 m
max. distance TITANUS® – T piece	20 m
max. branch length	25 m
max. overall pipe length per pipe system pipe Ø 25 mm plus pipe Ø 12 mm	50 m 8 x 3 m
max. overall pipe length per pipe system with a ventila- tor voltage of <10.5 V pipe Ø 25 mm plus pipe Ø 12 mm	40 m 8 x 3m
min. distance between 2 aspiration apertures (d)	4 m
max. distance between 2 aspiration apertures (d)	10 m
max. number aspiration apertures (n) per pipe system	8 no.

Aspiration apertures

Number of apertures per pipe system	2	4	6	8
Ø Aspiration aperture in mm ⁷⁾				
A	6,0	4,2	3,4	3,0
B	—	4,4	3,6	3,0
C	—	—	3,6	3,2
D	—	—	—	3,2

⁷⁾ Opening diameter of the aspiration reduction film

Trigger Thresholds U-pipe System

per pipe system

Number apertures	2	4	6	8
1 blocked aperture	± 25 %	± 15 %	— ⁸	—
2 blocked apertures	○ ⁹	± 25 %	± 20 %	± 15 %
3 blocked apertures	○	○	± 30 %	± 25 %
4 blocked apertures	○	○	○	± 35 %
5 blocked apertures	○	○	○	○
6 blocked apertures	○	○	○	○
7 blocked apertures	○	○	○	○
... is/are recognised if main air flow set at x %				

Example If the blockage of **3** aspiration apertures **out of** a total of **8** aspiration apertures is recognised, then with the aid of the diagnosis tool, air flow monitoring can be set to **±25 %**.



For a project planning according to EN 54-20, the air flow monitoring has to be adjusted to ≤20 % in either case.

⁸ — not possible

⁹ ○ not sensible

4.3.1.3 M-Pipe system

1 Pipe system TITANUS MICRO·SENS®




Fig. 4.8: M-Pipe system for area protection

Limit values

min. distance TITANUS® – T piece	2 m
max. distance TITANUS® – T piece	20 m
max. branch length	16,5 m
max. overall pipe length per pipe system Pipe Ø 25 mm plus pipe Ø 12 mm	50 m 8 x 3 m
max. overall pipe length per pipe system with a ventila- tor voltage of <10.5 V Pipe Ø 25 mm plus pipe Ø 12 mm	40 m 8 x 3m
min. distance between 2 aspiration apertures (d)	4 m
max. distance between 2 aspiration apertures (d)	10 m
max. number aspiration apertures (n) per pipe system	6 no.

Aspiration apertures

Number of apertures per pipe system	3	6
Ø Aspiration aperture in mm ¹⁰⁾		
A	5,0	3,6
B	—	3,8

¹⁰⁾ Opening diameter of the aspiration reduction film

Trigger Thresholds M-pipe System

per pipe system

Number apertures	3	6
1 blocked aperture	± 30 %	± 15 %
2 blocked apertures	○ ¹¹	± 30 %
3 blocked apertures	○	○
4 blocked apertures	○	○
5 blocked apertures	○	○
6 blocked apertures	○	○
... is/are recognised if main air flow set to x %		

Example If the blockage of **1** aspiration apertures **out of** a total of **6** aspiration apertures is recognised, then with the aid of the diagnosis tool, air flow monitoring can be set to **±15 %**.



For a project planning according to EN 54-20, the air flow monitoring has to be adjusted to ≤20 % in either case.

¹¹ ○ not sensible

4.3.1.4 Double-U-Pipe system

1 Pipe system

**TITANUS
MICRO·SENS®**




Fig. 4.9: Double-U-Pipe system for area protection

Limit values

min. distance TITANUS® – T piece	2 m
max. distance TITANUS® – T piece	20 m
max. branch length	12,5 m
max. overall pipe length per pipe system Pipe Ø 25 mm plus pipe Ø 12 mm	50 m 8 x 3 m
max. overall pipe length per pipe system with a ventilator voltage of <10.5 V Pipe Ø 25 mm plus pipe Ø 12 mm	40 m 8 x 3m
min. distance between 2 aspiration apertures (d)	4 m
max. distance between 2 aspiration apertures (d)	10 m
max. number aspiration apertures (n) per pipe system	8 no.

Aspiration apertures

Number of apertures per pipe system	4	8
Ø Aspiration aperture in mm ¹²⁾		
A	4,4	3,0
B	—	3,2

¹²⁾ Opening diameter of the aspiration reduction film

Trigger Thresholds Double U-pipe System

per pipe system

Number apertures	4	8
1 blocked aperture	$\pm 15 \%$	— ¹³
2 blocked apertures	$\pm 30 \%$	$\pm 15 \%$
3 blocked apertures	○ ¹⁴	$\pm 25 \%$
4 blocked apertures	○	$\pm 35 \%$
5 blocked apertures	○	○
6 blocked apertures	○	○
... is/are recognised if main air flow set to x %		

Example If the blockage of **3** aspiration apertures **out of** a total of **8** aspiration apertures is recognised, then with the aid of the diagnosis tool air flow monitoring can be set to **$\pm 25 \%$** .



For a project planning according to EN 54-20, the air flow monitoring has to be adjusted to $\leq 20 \%$ in either case.

¹³ — not possible

¹⁴ ○ not sensible

4.3.2 Simplified pipe design

Simplified pipe design is used for equipment protection and in areas with small dimensions. The advantage of this design is the unified diameters of the aspiration apertures.

For the project planning's, the specifications according to chapter 4.2 apply. Furthermore, the following limit values and opening diameters have to be considered. Additional accessories (air filter, steam traps etc.) can influence the maximum pipe length.

4.3.2.1 I-Pipe system

1 Pipe system

**TITANUS
MICRO·SENS®**




Fig. 4. 10: I-Pipe system, e.g. for equipment protection

Limit values

min. distance TITANUS® – 1 st aspiration aperture	2 m
max. distance TITANUS® – 1 st aspiration aperture	20 m
max. pipe length per pipe system Pipe Ø 25 mm plus pipe Ø 12 mm	40 m 5 x 3 m
max. overall pipe length per pipe system with a ventilator voltage of <10.5 V Pipe Ø 25 mm plus pipe Ø 12 mm	30 m 5 x 3 m
max. number aspiration apertures (n) per pipe system	5 no.
minimum distance between the aspiration apertures (d)	0,1 m
maximum distance between the aspiration apertures (d)	4 m
minimum distance for fire site location between the aspiration apertures (d)	3 m

Aspiration apertures

Number of apertures

Ø of all aspiration apertures
in mm¹⁵⁾

1	2	3	4	5
6,8	4,6	4,0	3,6	3,4

¹⁵⁾ Opening diameter of the aspiration reduction film

4.3.2.2 U-pipe system

1 Pipe system

**TITANUS
MICRO·SENS®**




Fig. 4. 11: U-pipe system, e.g. for equipment protection

Limit values

min. distance TITANUS® – T piece	2 m
max. distance TITANUS® – T piece	20 m
max. branch length	25 m
max. overall pipe length per pipe system Pipe Ø 25 mm plus pipe Ø 12 mm	50 m 8 x 3 m
max. overall pipe length per pipe system with a ventila- tor voltage of <10.5 V Pipe Ø 25 mm plus pipe Ø 12 mm	40 m 8 x 3 m
max. number of aspiration apertures (n) per pipe system	8 no.
minimum distance between the aspiration apertures (d)	0,1 m
maximum distance between the aspiration apertures (d)	4 m

Aspiration apertures

Number of apertures

Ø of all aspiration
apertures in mm¹⁶⁾

2	4	6	8
6,0	4,2	3,4	3,0

¹⁶⁾ Opening diameter of the aspiration reduction film

4.3.2.3 M-pipe system

1 Pipe system

**TITANUS
MICRO·SENS®**




Fig. 4. 12: M-Pipe system, e.g. for equipment protection

Limit values

min. distance TITANUS® – T piece	2 m
max. distance TITANUS® – T piece	20 m
max. branch length	16,5 m
max. overall pipe length per pipe system Pipe Ø 25 mm plus pipe Ø 12 mm	50 m 8 x 3 m
max. overall pipe length per pipe system with a ventila- tor voltage of <10.5 V Pipe Ø 25 mm plus pipe Ø 12 mm	40 m 8 x 3 m
max. number of aspiration apertures (n) per pipe system	6 no.
minimum distance between the aspiration apertures (d)	0,1 m
maximum distance between the aspiration apertures (d)	4 m

Aspiration apertures

Number of apertures	3	6
Ø of all aspiration apertures in mm ¹⁷⁾	5,0	3,6

¹⁷⁾ Opening diameter of the aspiration reduction film

4.3.2.4 Double-U-pipe system

1 Pipe system

**TITANUS
MICRO·SENS®**




Fig. 4.13: Double U-pipe system, e.g. for equipment protection

Limit values

min. distance TITANUS® – last T piece	2 m
max. distance TITANUS® – last T piece	20 m
max. branch length	12,5 m
max. overall pipe length per pipe system Pipe Ø 25 mm plus pipe Ø 12 mm	50 m 8 x 3 m
max. overall pipe length per pipe system with a ventila- tor voltage of <10.5 V Pipe Ø 25 mm plus pipe Ø 12 mm	40 m 8 x 3 m
max. number aspiration apertures (n) per pipe system	8 no.
minimum distance between the aspiration apertures (d)	0,1 m
maximum distance between the aspiration apertures (d)	4 m

Aspiration apertures

Number of apertures per pipe system	4	8
Ø of all aspiration aper- tures in mm ¹⁸⁾	4,4	3,0

¹⁸⁾ Opening diameter of the aspiration reduction film

4.3.3 Design for Forced Air Flow

Monitoring air conditioning ducts

Air conditioning plants are divided into low-speed and high-speed plants (see table below). The information given in this chapter applies **only to low-speed plants**. There is insufficient information from experience with high-speed plants. Where air conditioning ducts have flow speeds of more than 10 m/s, therefore, smoke testing must be carried out for the best reaction behaviour to be determined.

	Low speed plants	High speed plants
Flow speed	maximum 6 to 10 m/s	> 10 m/s
Duct cross-section	large	small
Differential pressures along the flow direction	small	large

The speed distribution in an air conditioning duct looks as follows:




Fig. 4.14: Speed distribution in an air conditioning duct with $v_1 > v_2 > v_3 > v_4$

Aspiration

To achieve optimum detection results, the pipe system must be arranged in the area v_1 to v_3 .

Location of the pipe system

To achieve the best location for constructing the pipe system, the exhaust duct should be as far as possible from sound dampers, air baffle plates and kinks. The guideline figure for the distance from such "obstacles" is at least 3 x the smallest duct diameter.

If it is absolutely essential to fit the pipe system directly behind baffle plates, sound dampers or bends, the main speed areas must be monitored (see Fig. 4.15/16).




Fig. 4.15: Duct direction change **without** baffle plates




Fig. 4.16: Sound dampers in a duct

When a pipe system is built into air conditioning ducts, the following must be observed:

- As the TITANUS MICRO·SENS® and the pipe system are in different pressure areas, there must be an air return arrangement (see following page).
- The pipe entries into the duct must be sealed air-tight.
- The part of the pipe system which is outside the duct must be bonded air-tight.




Fig. 4.17: Air return

The open end of the air return pipe is chamfered at an angle of 45° .

The distance between the aspiration apertures and between them and the duct wall is shown in the following table.

Hole distances

	Duct cross-section $\leq 0.5 \text{ m}^2$	Duct cross-section $> 0.5 \text{ m}^2$
Distance from aspiration apertures to the wall	100 to 200 mm	200 to 300 mm
Distance between the aspiration apertures	100 mm	150 mm

Diameter of the aspiration apertures

The diameter of the aspiration apertures results from the number of aspiration apertures. The exact figure can be found in Chapter 4.6.3 "Simplified Pipe Design".

The pipe is closed by an end cap without a hole.

Arrangement The aspiration apertures are to be arranged against the air flow.

Take care in the design that, for assembling the pipe system, the air conditioning ducts are often only accessible from two sides.

Example The following figure shows two design examples of pipe systems in air conditioning ducts.




Fig. 4.15: Ducts with small and large duct cross-section

4.4 Power Supply

When sizing the power supply, the signal-ready status of the danger alarm equipment and the alarm case are considered. When the plant is in the signal-ready status, the power supply must deliver the idling current to the air sampling smoke detection systems and guarantee charging of the stand-by accu in accordance with DIN VDE 0833, Part 1¹⁹.

The following formulae apply in case of alarm:

Power calculation In case of alarm the current is calculated by the following formula:

Room protection

$$I_{total, room} = I_{alarm} \cdot n_{max, area} + I_{quiescent} (n - n_{max, area}) \leq I_{powersupply, max.}$$

Equipment protection

$$I_{total, equipment} = I_{alarm} \cdot \sqrt{n} + I_{quiescent} (n - \sqrt{n}) \leq I_{max, power}$$

The current for charging the accu is calculated by the following formula:

Charging current

$$I_{charging} \approx \frac{0,8 \cdot K_{nominal}}{24}$$

$$I_{total, equipment} = I_{quiescent} \cdot n + I_{charging} \leq I_{powersupply, max.}$$

I_{total}	=	total current of all connected air sampling systems [A]
$I_{power supply, max.}$	=	max. supply current of the power supply unit [A]
n	=	total number of all air sampling systems connected to a power supply unit
$n_{max, area}$	=	total number of all air sampling systems in the area with the highest power consumption
I_{alarm}	=	alarm current of an air sampling system [A]
$I_{quiescent}$	=	quiescent current of an air sampling system [A]
$K_{nominal}$	=	nominal capacity of the accumulators [Ah]
$I_{charging}$	=	charging current of the accumulators (within 24 h 80% of the nominal capacity) [A]



The higher figure of the total current calculated (I_{total}) is used to design the power supply!

The power consumption of the TITANUS MICRO·SENS® can be found in Chapter 3, "Technical Data".

¹⁹ 80% charging in 24 hours

Line calculation

The maximum line length results from the permitted line drop on the feed. The permitted line drop is the difference resulting from the stand-by accus discharge voltage (21.5 V) and the lower operating voltage limit of the aspiration smoke detection system.

$$L_{max} = \frac{\gamma \cdot \Delta U \cdot A}{I_{total} \cdot 2}$$

L_{max} = Maximum line length in [m]

A = Wire cross-section in [mm²]

I_{total} = Total current of the aspiration smoke detection system in [A]

γ = Conductivity: Cu=57m/Ωmm²

ΔU = Max.line drop on the feed

To guarantee the tightness of the housing seal, the appropriate cable throughput for the particular cable must be selected.

- M 25- cable throughput: Ø 9 to 14 mm
- M 20- cable throughput: Ø 8 to 12 mm

Emergency Supply Calculation

The nominal capacity is calculated by means of the following formula:

$$K_{nominal} = (I_{quiescent} \cdot n \cdot t + I_{total} \cdot 0.5h) \cdot 1.25$$

$K_{nominal}$ = nominal capacity of the emergency supply accumulators [Ah]

t = required bridging time [h]

The factor 1.25 in the equation is only to be observed if bridging times are smaller equal to [sic] 24 hours.

5 Installation

TITANUS MICRO·SENS®

5.1 General

The regulations, guidelines and provisions set out in Chapter 4.1 apply.

The following must be considered when the TITANUS MICRO·SENS® aspirating smoke detector is being installed:

1. Interventions, changes and modifications to equipment are to be avoided. If adjustments are unavoidable, they must be discussed with the operator, the manufacturer and/or the supplier (written approval).
2. All interventions to the in-house network (230 V/400 V supply) and to outside systems must be carried out on the customer side. These include, for example:
 - the power supply primary connection
 - any connecting to outside systems (e.g. central units)
 - the carrying out of any lightning and surge protection measures which are required to comply with standards

5.2 Installation site

5.2.1 Fitting the TITANUS MICRO·SENS® air sampling smoke detector

When choosing the installation site, ensure that the notices can be easily seen.



When choosing the installation site, ensure that it is not within a space where doors open.




Fig. 5.1: Installation of TITANUS MICRO·SENS®

Aspiration from above

Ensure that the air outlet from the aspirating smoke detector is not blocked. Maintain a distance of **at least** 10 cm between the air outlet from the TITANUS MICRO·SENS® and surrounding objects (e.g. wall).

**Aspiration
from below**

If the TITANUS MICRO·SENS® is installed with the aspiration pipe underneath, ensure that no foreign bodies or drops of water can get into the air outlet aperture which in this case is facing upwards. For that reason, use a short pipe angled downwards (see Fig. 5.1).



With aspiration from below, the housing cover on the TITANUS MICRO·SENS® must be turned by 180°.




Fig. 5. 2: Turn the cover of the TITANUS MICRO·SENS® detection unit

To turn the cover of the TITANUS MICRO·SENS® detection unit by 180°, the following steps must be taken:

Turn cover

- ❶ Release the 4 screws (for position see Fig. 5.2).
- ❷ Now turn the cover and fix the detection unit again with the 4 screws.

Installation equipment**TITANUS®**

- Cylinder or flat head screws
- Thread diameter: max. 4 mm
- Head diameter: max. 8 mm

Hole distances

The dimensions (all dimensions in mm) of the holes for fixing the TITANUS MICRO·SENS® are shown in the following Figures.




Fig. 5.3: Hole distances TITANUS® MICRO·SENS® base unit

5.2.2 Connecting the air sampling pipe




Fig. 5.4: Connecting the aspiration pipe to the TITANUS MICRO·SENS® air sampling smoke detector

When connecting the air sampling pipe to the TITANUS MICRO·SENS® the following steps must be taken:

Connecting the air sampling pipe

- 1 To join the air sampling pipe to the TITANUS MICRO·SENS®, push it into the pipe connection provided for the purpose.



Under no circumstances use adhesive to join the air sampling pipe and pipe connection together.
Where there are widely oscillating temperatures, the pipe must be fixed firmly immediately in front of the device such that the pipe is not pulled out of the connection by changes in length which occur (see Chapter 6.1).

5.3 Incorporation and electrical connection of additional modules

To prepare the electrical connections, the following steps must first be taken:

1. Make the number of cable entries required on the device base unit, e.g. with a screwdriver.
2. Put the cable entries M20 and/or M25 into the corresponding cable holes.
3. Feed the cable through the corresponding cable holes.



2x M20 and 1x M25 cable entries are supplied with the device.

The electrical connection is made via screw terminals 1a to 8a and 1b to 8b on the TITANUS MICRO·SENS® base unit. In so doing, note the permitted cable cross-sections on the threaded joints and the permitted wire cross-sections on the terminals for a max. 0.5 mm²-2.5 mm² wires.




Fig. 5.5 : Layout of screw terminals in the device base unit



Carry out all connection work to the device with the power off!




Fig. 5.6: Arrangement of screw terminals in the device base unit

Alarm and fault contact can be used, for example, to connect to a CFDU or to control signals, guidance systems etc. There is also the option of connecting a parallel display or reaction indicators to the device indicator bus.



Permanent wiring in the reset input leads to all messages being automatically reset when the cause of the message has been removed.

Additional housing

If additional modules or a parallel display are used, then an installation plate is screwed into the base unit of the additional housing.




Fig. 5.7: Positioning of the installation plate in the additional housing base unit

The installation plate is for all additional modules and prefabricated for the parallel display switching power supply.




Fig. 5.8: Arrangement of holes on the installation plate of the additional housing

5.4 Connection to CFDU, with reset button




Fig. 5.9: Example of connecting TITANUS MICRO·SENS® to a CFDU and reset button

5.5 Incorporating the reset board

The reset board can be used as an option for the TITANUS MICRO·SENS®. The reset board is mounted in an additional housing. If several TITANUS MICRO·SENS® are connected to a detection line, then the reset board is only connected into the detection line after the last TITANUS MICRO·SENS®. The electrical connection to the reset board is as per the switching plan (see Fig. 5.10).



The reset board can only be used if the idling current on the detection line is between 5 mA and 50 mA and the detection line terminal has an ohmic resistance. The reset impulse is triggered if the line voltage falls below 3V when the central unit is reset.

Line idling current

The idling current I_R on the line is calculated as follows:

$$I_R = \frac{U_L}{R_E}$$

where R_E = Original terminating resistor of the line in [Ω]
 U_L = Line voltage in [V]
 I_R = Idle current on the line in [A]

The formulae shown for calculating the terminating resistor and the idling current on the detection line take account of the ideal status for signal evaluation.

If no acknowledgement is given from calculating the reset board terminating resistor, the value of the terminating resistor must be reduced by about 20 %.

Terminating resistor

The reset board balances the detection line terminating resistor. It is calculated afresh and incorporated in the reset board (Connection X1, see Fig. 5.10). The value of the terminating resistor R_{ER} is calculated as follows:

$$R_{ER} = \frac{(U_L - 2,7V)}{I_R}$$

where R_{ER} = Terminating resistor on the reset board in [Ω]
 U_L = Line voltage in [V]
 I_R = Idling current on the line in [A]




Fig. 5.10: Fitting the reset board into the TITANUS MICRO·SENS® additional housing

Fitting To fit the reset board into the TITANUS MICRO·SENS® additional housing, the following steps must be taken:

- ➊ Using a screwdriver, loosen the four screws on the additional housing cover.
- ➋ Put the terminating resistor ¹ R_{ER} as calculated into the connecting terminal X1.
- ➌ Fix the reset board to the installation board with 3 plastic spacers (for fixing points see Fig. 5.8) in the additional housing.
- ➍ The electrical connection (terminal strip 8a/b) is described in section 5.5.1.
- ➎ Fix the cover on again by screwing down the four screws on the device cover firmly using a screwdriver.

¹ Terminal resistor not supplied, performance 1/4W

5.5.1 Connection to a CFDU, with reset board




Fig. 5.11: Example of connecting a TITANUS MICRO·SENS® to a CFDU and reset board

5.6 Incorporating the reset and isolating button board

If a reset or isolating button is needed, the plate must be fitted into an additional housing.




Fig. 5.12: Incorporating the reset and isolating board into the TITANUS MICRO·SENS® additional housing

Fitting Proceed as follows to incorporate the reset and isolating button board:

- ❶ Using a screwdriver, loosen the four screws on the additional housing cover.
- ❷ Push the spacer blocks into the installation board (for fixing points see Fig. 5.8) on the additional housing. The reset and isolating button board is then engaged with the spacer blocks using the holes provided.
- ❸ Feed the wires through as per the following switching plan.
- ❹ Fit the cover again, using a screwdriver to fit the four screws on the device cover firmly.

5.6.1 Function switching plan, reset and isolating button board




Fig. 5.13: Example of TITANUS® connections with reset and isolating button board

5.7 Incorporating the relay board RU-1/RU-2

If a relay board are needed, the board must be fitted into an additional housing.




Fig. 5.14: Incorporating the relay board into the TITANUS MICRO·SENS® additional housing

Fitting Proceed as follows to incorporate the relay board:

- ❶ Using a screwdriver, loosen the four screws on the additional housing cover.
- ❷ Push the spacer blocks into the installation plate (for fixing points see Fig. 5.8) on the additional housing. The relay board is then engaged with the spacer blocks using the holes provided.
- ❸ Feed the wires through as per the following switching plan.
- ❹ Fit the cover again, using a screwdriver to fit the four screws on the device cover firmly.



An additional housing of TITANUS MICRO·SENS® is required per relay board. Maximal 2 relay boards or remote display units can be connected to the device.

5.7.1 Function switching plan, relay board RU-1




Fig. 5.15: Example of TITANUS MICRO·SENS® connections with relay board RU-1

5.7.2 Function switching plan, relay board RU-2




Fig. 5.16: Example of TITANUS MICRO·SENS® connections with relay board RU-2

5.8 Using TITANUS MICRO·SENS® in the AlgoRex® fire alarm system

There are various options for connecting the floating alarm and fault contacts in the TITANUS MICRO·SENS® to the AlgoRex® fire alarm system:

- Connection to collective lines
- Use of line components with AnalogPLUS® technology
- Connection using interactive line components

5.8.1 Collective Connection

The TITANUS MICRO·SENS® can be connected to a collective line card (component of the central unit) in the AlgoRex® fire alarm system or to other collective fire alarm central units. To do that, the alarm contact and the fault contact are joined with a collective detection line. Fig. 5.17 shows the preferred connections for the TITANUS MICRO·SENS®.



Ensure the correct polarity when 5.6 V Z diodes are used.

5.8.2 Function switching plan, collective connection




Fig. 5.17: Collective collection of TITANUS MICRO·SENS® with reset button

5.8.3 Use of the TITANUS MICRO·SENS® with AlgoRex® line components

The TITANUS MICRO·SENS® can be connected to the AlgoRex® fire alarm system with the corresponding line components (AnalogPLUS® or interactive). Installation of the line components required takes place in the TITANUS MICRO·SENS® additional housing.

5.8.3.1 Installation of AlgoRex® line components into the TITANUS MICRO·SENS® additional housing

The TITANUS MICRO·SENS® is supplied without line components or the associated installation kit. These are to be incorporated into an additional housing to complement the device.




Fig. 5.18: Fitting the line components into the TITANUS MICRO·SENS® additional housing

Fitting To fit the line components, proceed as follows:

- ❶ Using a screwdriver, loosen the four screws on the additional housing cover.
- ❷ Fix the line component to the installation plate using the fitting equipment from the kit (for fixing points see Fig. 5.8).
- ❸ Feed the wires through according to the following switching plan.
- ❹ Re-fit the cover by using a screwdriver to screw the four screws to the device cover firmly.



Also comply with the installation instructions enclosed with each line component.

5.8.3.2 TITANUS MICRO·SENS® and AnalogPLUS technology




Fig. 5.19: Connection in AnalogPlus technology

5.8.3.3 TITANUS MICRO·SENS® and interactive technology




Fig. 5.20: Connection in interactive technology

5.9 TITANUS MICRO·SENS® in a network

Several TITANUS MICRO·SENS® can be connected optionally into a network. This network system allows the user to monitor the status of all connected TITANUS MICRO·SENS®. For this, for example, the pattern of smoke levels, air flow values and the alarm and fault status are transmitted via the bus system.

To operate the TITANUS MICRO·SENS® in a network, special PC software and a network module for additional housing are required which are not supplied with the TITANUS MICRO·SENS®.

5.9.1 Fitting the network module into the TITANUS MICRO·SENS® additional housing




Fig. 5.21: Fitting the network module into the additional housing

To fit the network module, first open the additional housing. The following steps are to be taken:

- ❶ With the aid of a screwdriver, loosen the four screws on the additional housing cover.
- ❷ Fit the network module into the TITANUS MICRO·SENS® additional housing (for fixing points see Fig. 5.8).
- ❸ The network module is connected as per Fig. 5.22. Push the network cable into the RJ45 socket.
- ❹ Refit the cover using a screwdriver to screw the four screws on the device cover firmly.

5.9.2 Connecting the Network Module

The network module creates the connection between the bus system and the TITANUS MICRO·SENS®. Fig. 5.22 shows the electrical switching plan which must be followed for this in the aspirating smoke detector.



To operate the TITANUS MICRO·SENS® in a network, more information is needed about the bus system and the PC software.




Fig. 5.22: Connecting the network board

5.10 Parallel displays

5.10.1 Connecting the parallel displays to TITANUS MICRO·SENS®




Fig. 5.23: Connection of parallel display to TITANUS MICRO·SENS®

To connect the parallel display, take the following steps:

- ❶ Using a screwdriver loosen the four screws on the TITANUS MICRO·SENS® detection unit.
- ❷ Feed the fire alarm cable through the cable entry on the TITANUS MICRO·SENS® device base unit.
- ❸ Feed the wires to the terminal block on the base unit according to the switching plan (see Fig. 5.25).
- ❹ Refit the detection unit by using a screwdriver to screw the four screws on the detection unit of the device cover down firmly.

5.10.2 Parallel display housing

Fitting the front film




Fig. 5.24: Fitting the front film for the parallel display

With the parallel display the cable entry can be above, below or at the side without the cover having to be turned. The switching power supply for the parallel display is fitted to the installation plate of the parallel display housing (for fixing points see Fig. 5.8).

Wall fixing The device base unit for a parallel display is screwed directly onto a wall.

Installation equipment

Parallel display	Cylinder or flat head screws – Thread diameter: max. 4 mm – Head diameter: max. 8 mm
------------------	--

Hole distances The drilling template is shown in the Fig. 5.3 (all dimensions in mm).

5.10.3 Electrical connection

Connect the parallel displays via the terminal block 7b and 8b indicator bus on the device base unit of the TITANUS MICRO·SENS®. The power is supplied via TITANUS MICRO·SENS® or for greater distances, externally. Calculate the lines as for TITANUS MICRO·SENS®, in accordance with Chapter 4.8 "Power Supply".

You must comply with the permitted cable cross-sections for the particular cable throughputs and the permitted wire cross-sections for the terminals (see Chapter 3 "Technical Data").

Parallel display Connect the parallel display **to the TITANUS MICRO·SENS® with the power off** as follows:




Fig. 5.25: Connecting the parallel display to TITANUS MICRO·SENS®



Maximal 2 relay boards or remote display units can be connected to the device.

5.11 Reaction indicator

5.11.1 Addressing the reaction indicators




Fig. 5.26: Reaction indicator board with fire location

Addressing the up to 5 reaction indicators happens by setting up switch S1 on the board.




Fig. 5.27: Example of addressing the reaction indicators

The reaction indicators are tested using the diagnostic tool (see Chapter 7 Commissioning).




Fig. 5.28: Testing the reaction indicators by menus of the diagnostic tool

5.11.2 Connecting the reaction indicator to the TITANUS MICRO·SENS®

Connect the reaction indicators via terminal block 7b and 8b indicator bus on the TITANUS MICRO·SENS® device base unit. The power is supplied by the TITANUS MICRO·SENS®.




Fig. 5.29: Connecting the reaction indicators to TITANUS MICRO·SENS®

5.12 Inserting the detection unit in the device base unit




Fig. 5.30: Installing the TITANUS MICRO·SENS® aspirating smoke detection system



ATTENTION

The components on the board are to be protected against damage from electrostatic charges.

Proceed as follows to insert the TITANUS MICRO·SENS® in the device base unit:

- ❶ Put the device in the pre-mounted device base. When inserting the detection unit, note the mechanical coding, this protects the device against twisting.
- ❷ Screw the four screws on the detection unit down tight using a screwdriver.

5.13 Settings

5.13.1 Detection Unit

All settings are undertaken using the diagnostic tool. Installation of the diagnostic tool for TITANUS MICRO·SENS® and its application are described in Chapter 7.




Fig. 5.31: Sensitivity, Alarm Delay, Air Flow Area and Fault Delay settings




Fig. 5.32: Height, Air Pressure and Fan Voltage settings

In the diagnostic software, the current TITANUS MICRO·SENS® figures are displayed on the Settings screen.

The figures can be changed by pressing the Settings button.

5.13.1.1 Setting reaction sensitivity

The sensitivity (fire alarm) of the detection unit can be set using the TITANUS MICRO·SENS® diagnostic tool.

	Sensitivity	Sensitivity Standard	Settings stages
Detection unit DM-TM-10	0,1 - 2 %/m	0,1 %/m	0,1 %/m
Detection unit DM-TM-50	0,5 - 2 %/m	0,5 %/m	0,1 %/m

5.13.1.2 Delay time for triggering the alarm

The standard set for the delay time for the alarm threshold can be changed using the diagnostic tool. The standard delay time for the alarm is set to 10 secs. If the smoke level during operation rises to the alarm threshold, the delay time starts running. Only when the delay time has run out and if the smoke levels are still rising is the message forwarded. In this way false alarms caused by short-term loads (e.g. dust) can be avoided.

	Alarm delay	Alarm delay Standard	Settings stages
Detection unit DM-TM-10	0 s – 60 s	10 s	1 s
Detection unit DM-TM-50/	0 s – 60 s	10 s	1 s



TIP

The alarm delay time should be set to 0 seconds only for testing purposes.

5.13.1.3 Threshold for air flow monitoring

The threshold for air flow monitoring can be changed for the detection unit by using the diagnostic tool for TITANUS MICRO·SENS®.

	Threshold	Threshold Standard	Settings stages
Detection unit DM-TM-10	10 % - 50 %	20 %	1 %
Detection unit DM-TM-50	10 % - 50 %	20 %	1 %

Select the trigger threshold in accordance with Chapter 4, "Design".

5.13.1.4 Delay time for air flow fault

If you want to change the delay time for forwarding an air flow fault, this can be done by using the diagnostic tool for TITANUS MICRO·SENS®.

	Fault delay	Fault delay Standard	Settings stages
Detection unit DM-TM-10	1 s – 60 min	100 s	1 s
Detection unit DM-TM-50	1 s – 60 min	100 s	1 s

The standard delay time setting is 100 seconds. In areas with time-limited fault variables (e.g. air pressure oscillations), then depending on the duration of the fault variables, other delay times should be set.

5.13.1.5 Action-Alarm Threshold

Action-Alarm threshold changes for “Fire alarm after ROOM IDENT » can be carried out by the diagnostic tool for TITANUS MICRO·SENS®.

	Action -Alarm Threshold	Action -Alarm Threshold Standard	Settings stages
Detection unit DM-TM-10	10 – 80 %	60 %	1 %
Detection unit DM-TM-50	10 – 80 %	60 %	1 %

Default value for Action -Alarm threshold is set to 60% of the Fire Alarm threshold.

5.13.1.6 Fault display

The displaying of collective fault (air flow and detection unit fault) can, as preferred, be set to storing or not storing (standard). This is activated or deactivated by using the diagnostic tool for TITANUS MICRO·SENS®.

	Fault storing	Fault not storing Standard
Detection unit DM-TM-10	off – on	off
Detection unit DM-TM-50	off – on	off

5.13.1.7 Dynamic air flow

The dynamic air flow is activated or deactivated by using the diagnostic tool for TITANUS MICRO·SENS®.

	Dynamic air flow	Dynamic air flow Standard
Detection unit DM-TM-10	off – on	off
Detection unit DM-TM-50	off – on	off

5.13.1.8 ROOM-IDENT

Location of a fire is activated or deactivated by using the diagnostic tool for TITANUS MICRO·SENS®.

	ROOM-IDENT	ROOM-IDENT Standard
Detection unit DM-TM-10	off – on	off
Detection unit DM-TM-50	off – on	off

5.13.1.9 LOGIC·SENS

LOGIC·SENS intelligent signal processing can be activated or deactivated by using the diagnostic tool for TITANUS MICRO·SENS®. If signal evaluation is switched on, **LOGIC·SENS** prevents false alarms by recognising short-term fault variables.

	LOGIC·SENS	LOGIC·SENS Standard
Detection unit DM-TM-10	off – on	on
Detection unit DM-TM-50	off – on	on

5.13.1.10 Fire Alarm threshold after ROOM-IDENT

It can be useful for certain applications to activate the alarm after the localisation of the fire has completed. By using the diagnostic tool for TITANUS MICRO·SENS® it is possible to enable or disable the function "Fire alarm after ROOM IDENT ». Please note, that the function «ROOM IDENT» has to be enabled as well when using this option. Otherwise localisation will not be performed.

	Fire alarm after ROOM-IDENT	Fire alarm after ROOM-IDENT Standard
Detection unit DM-TM-10	off – on	off
Detection unit DM-TM-50	off – on	off

"Fire alarm after ROOM IDENT « is disabled by default.

5.13.1.11 Setting the ventilator voltage

The standard setting for the ventilator voltage is 9 V. In critical applications the ventilator voltage can be set higher by using the TITANUS MICRO·SENS® diagnostic tool, to raise the transport speed in the pipe system and thus guarantee faster detection where there are longer pipe runs.

With a ventilator voltage of 9 V to 10.4 V the maximum pipe lengths are reduced to 30 m for the I-pipe and 40 m for the U and Double U-pipe designs. From a ventilator voltage of 10.5 V upwards, the maximum pipe length is given.

	Ventilator voltage	Ventilator voltage Standard	Settings stages
Detection unit DM-TM-10	9 V – 13,5 V	9 V	0,1 V
Detection unit DM-TM-50	9 V – 13,5 V	9 V	0,1 V



If the TITANUS MICRO·SENS® ventilator voltage is changed, the device automatically carries out air flow initialisation.

5.13.1.12 Inputting the current air pressure

The current air pressure for the monitoring area must be input by using the TITANUS MICRO·SENS® diagnostic tool if air pressure-dependent adjustment is required.

The standard setting is 1013 hPa, corresponding to the average air pressure at sea level.

5.13.1.13 Inputting height above Normal Sea Level (NN)

The figure for the height above normal sea level is that for the installation site of the TITANUS MICRO·SENS® above sea level. The figure is input by using the diagnostic tool. The standard setting is 0 m. The figure has to be changed if the device's air flow sensory analysis has to be balanced because of the air pressure (see Chap.7).



If the standard setting for air pressure or the height above sea level is changed, the TITANUS MICRO·SENS® air flow is automatically re-initialised.

5.13 Data Logging

A simple device check can be run using the diagnostic tool. By reading messages and statuses, the diagnostic program offers a considerably simplified service.

DIAG 3 can be fastened to the TITANUS MICRO·SENS® by an device bracket or attached in a straight line ($\pm 10^\circ$) of up to 3 m distance to the infrared interface.

The data are read via an infrared interface on the TITANUS MICRO·SENS® using the DIAG 3 which is connected to the USB interface on the PC by a USB cable.

Commissioning of the diagnostic software is described in Chapter 7 "Commissioning".




Fig. 5.33: Connecting a PC to the TITANUS MICRO·SENS®



TIP

It is recommended that, in order to check the device settings later, they are stored and archived after commissioning.

6 Installation Pipe System

The pipes and fittings used for the pipe system must always meet requirements for Class 1131 in accordance with EN 61386-1, 2004.

Class 1131 puts the following requirements on the pipe system used:

characteristics	severity code
compression resistance	125 N
impingement resistance	0,5 kg, drop height at 100 mm
temperature range	-15 °C to +60 °C

In principle, the following pipes as well as the related fittings are to be used in configuring the pipe system:

	external diameter	internal diameter	
		ABS	PVC
air sampling pipe	25 mm	21,4 mm	21,2 mm



ATTENTION

Take note of the temperature range specified in the "Technical data" chapter under "3.3 Pipe system" when configuring the pipe system.

installation instructions

The pipe system is to be constructed to suit the project and in compliance with the design guidelines (see Chapter 4 "Design").

1. Shorten the pipes using a pipe cutter or a metal saw. De-burr the interfaces and then clean them of any swarf.
2. Clean the adhesion points of dirt and grease **before** using the adhesive, using the prescribed cleaner. Then stick the pipe junction pieces to the associated fittings so that they are air-tight.

Air Sampling Pipe, halogen-free	Air Sampling Pipe (PVC)	Cleaning Agent	Adhesive	Pipe Cutter
ABSR-2518,	R-2519,	Tangit cleaner	Tangit adhesive	Pipe shears or cutter 38 mm



ATTENTION

Adhesives and cleaning products contain solvents and are flammable. It is essential to observe the supplier's safety information before processing.

3. Keep the pipe lengths and direction changes to a minimum. Elbows and bends have an extremely high flow resistance. Use them only where this is unavoidable. Should this be necessary, the pipe length must then be reduced in relation to the fitted bends¹.



INSTRUCTION

Arcs should be used instead of elbows. If there are too many direction changes, an air flow fault can occur in TITANUS® and detection time can be affected.

4. The pipes must be installed in such a way that they do not sag or move. They are fixed with pipe clips **without** rubber core. The space between the pipe clips should be no more than 80cm. Reduce the space between clips to no more than 30cm if there are high temperature variations.



INSTRUCTION

Do not use pipe clips with rubber cores as these do not expand lengthwise and the pipes would sag or crack.

5. Close open pipe ends with end caps.



INSTRUCTION

After pipe installation is complete, check for the following:

- air tightness (e.g. due to damage)
- any faulty connections
- correct projection of the air sampling points

¹ An arc equals a straight piece of pipe of 0.3m
an elbow equals a straight piece of pipe of 1.5m

6.1 Linear expansion of the pipe system

Linear expansions (lengthening or shortening) of the pipe system are caused by variations in temperature. An increase in temperature results in lengthening of the pipe, a decrease in temperature shortens the pipe. It is very important to take this into consideration if the installation temperature differs considerably in comparison to the operating temperature.

The length change can be calculated with the following formula:

$$\Delta L = L \times \Delta T \times \delta$$

ΔL = linear expansion in (mm)
 L = length of the pipe to be calculated in (m)
 ΔT = maximum temperature difference in (°C)
 δ = length change co-efficient in mm/m°C
 $\delta_{PVC} = 0.08 \text{ mm/m°C}$
 $\delta_{ABS} = 0.101 \text{ mm/m°C}$

For example, a temperature variation of 10° C in an ABS pipe with a length of 10 m results in an expansion of 10.1 mm.

Pipe clips As a rule, plastic pipe clips, type 23, are used for the installation of pipe systems (Ø 25mm). They do not allow for linear expansion and in areas with high temperature variations the plastic pipe shells, type CLIC-PA must be used. (see fig. 6.1).




Fig. 6.1: Pipe clips

There are two fixing points for the plastic pipe clip CLIC-PA when installing the pipes:

1. **Position 1 (first locking into place):**
Fixes the pipe so that a linear expansion is possible (used in deep freeze areas, if necessary).
2. **Position 2 (second locking into place):**
Fixes the pipe and avoids linear expansions.

Pipe Clips for ø 25 mm	Type
standard pipe clips	pipe clip type NG 23 (ø 25 mm)
pipe clips for areas with high temperature differences and deep freeze areas	plastic pipe clip Type CLIC-PA (ø 25 – 28 mm)
pipe clips for deep-freeze areas and high rack storage areas	spring steel clip type SNAP CLIP SC (for profiles 1-4 mm) spring steel clip, type SNAP CLIP SC (for profiles 4-7 mm) spring steel clip, type SNAP CLIP SC (for profiles 8-12 mm)

6.2 Patented air sampling points




Fig. 6.2: Example of an air sampling point with aspiration-reducing film sheet

Air sampling point Design air sampling points (bore holes) and their positioning according to project requirements and pipe design guidelines.

Air Sampling Holes

1. Bore a hole with a 10mm drill at a right angle to the pipe.
2. Carefully de-burr the holes.
3. Clean the area around the hole (around the whole pipe) from dirt and grease with Tangit cleaner.
4. Select the size of the aspiration-reducing film sheet according to the pipe design guidelines
5. Stick the aspiration-reducing film sheet over the bore hole (see fig. 6.3, ①).
6. Prevent the film sheet from coming loose by sticking marking tape over it (see fig. T.3, ②).



The perforations in the aspiration-reducing film sheet and the marking tape are to be placed exactly on the hole in the pipe. The diameter of the perforation in the aspiration-reducing film sheet must not be changed. Avoid touching the adherend in order to keep it free from dust and fat.




Fig. 6.3: Attaching the aspiration-reducing film sheet

6.3 Ceiling lead through




Fig. 6.4: Installation of ceiling feed-through

To install the ceiling feed-through use the following steps:

- ➊ **Before** gluing remove dirt and grease with the recommended cleaner.
- ➋ Glue the hose connector to the corresponding T-piece with Tangit glue.
- ➌ For each ceiling feed-through drill a hole of \varnothing 13mm through the false ceiling.
- ➍ Install the lead-through by first removing the nut, pushing the hose sleeve from the bottom through the bore hole and then re-placing and tightening the nut above the false ceiling.
- ➎ Determine the required length and cut the air sampling hose. Attach the hose to the sleeve of the ceiling feed-through and the hose connector at the T-piece of the air sampling pipe. If necessary soften the hose ends with a hot air fan.
- ➏ Stick the correct aspiration-reducing film sheet (according to pipe design guidelines) to the ceiling feed-through.

The aspiration-reducing film sheets are available in two colours. Depending on the colour of the ceiling, either type AFW-x (pure white, RAL 9010) or type AF-x (papyrus white, RAL9018) are used. On request, film sheets in special colours are produced.



The perforation of the aspiration-reducing film sheet must be placed exactly over the opening of the ceiling lead-through and the diameter of the hole in the film sheet must not be altered. To keep the gluing surface of the film sheet free of dust and grease, avoid any contact.

6.4 Monitoring in forced air flow systems (ventilation or climatic applications)

6.4.1 Detection at air inlets/outlets



If aspiration takes place in a forced air flow system (ventilator, climatic systems), the air sampling points must be positioned in the air flow. Place the air sampling points as shown in fig. 6.5.




Fig. 6.5: Positioning of air sampling point, depending on air speed

6.4.2 Detection in bypass systems

For connection of air return refer to chapter 6.6 "Air Return".




Fig. 6.6: Positioning of air return, example of a climatic duct (bypass)

For the pipe design of TITANUS MICRO·SENS® in these areas see chapter 4.3.4 "Pipe Design for Forced Air Flow".

6.5 Filter

6.5.1 Installation of air filter, type LF-AD-x




Fig. 6.7: Spacing for bore holes on base of air filter housing

Air Filter LF-AD-x

1. To fit the filter into the pipe system, use the two PG29 filter screw-joints.
2. Fix these screw-joints in the same way as the pipe adapter.
3. When installing the filter, ensure that the direction of air flow is shown at the side of the housing's bottom part.
4. Screw the bottom part of the housing directly to the wall.

Installation Material

Air Filter	cylinder or flat-head screws – thread diameter: max. 4 mm – head diameter: 5 to 7 mm
------------	--

6.5.2 Mounting of the special filter type SF-400/650




Fig. 6. 8: Mounting of the special filter into the pipe system

Special filter SF-x

1. To install or un-install the special filter use the two PVC reducer screw joints at both filter ends.
2. Glue the reducer couplings into the pipe system.
3. When installing the special filter, note the flow direction shown on the filter housing.
4. Clamp the special filter with a 45° elbow piece to the pipe system.

Installation material

Special Filter	PVC or ABS pipe fittings – 45° elbows
----------------	--

6.6 Air return




Fig. 6.9: Mounting of the air return

Feed the air return into the pipe connection provided on the TITANUS MICRO-SENS®. As the air return pipe sits perfectly in the connection, it will be held securely.



The air return is to be fixed immediately in front of the device, so that the pipe is not pulled out of the pipe connection by any changes in length which occur (see Chapter 6.1).

6.7 Noise suppressor




Fig. 6.10: Mounting of noise suppressors

- ❶ Pass the pipe (\varnothing 25mm) through the opened feed-through in the protection grid and fix it with the existing pipe collar in the air outlet of TITANUS®. As the air return pipe fits exactly into the exit air opening, a tight fit is ensured.
- ❷ Use the sound suppressor's PG29 screw connection in order to connect the noise suppressor to the pipe.
- ❸ When installing the absorbing duct, ensure that the direction of air flow is shown at the side of the housing's bottom part.
- ❹ Screw the bottom part of the housing directly to the wall.

Installation material

Noise suppressor	cylinder or flat-head screws – thread diameter: max. 4 mm – head diameter: 5 to 7 mm
------------------	--

6.8 3-Way ball valve




Fig. 6.11: Installation of 3-way ball valve

The ball valve is used for blowing through with compressed air (preferably) or pressed air². Switching occurs between detection (position 0°) and blow-through (position 180°). Connect the ball valve to the pipe system via reducing screw-joints.

Connections

During installation, ensure that the correct connections are made (see diagram in fig. 6.11):

- connect the air sampling pipe system to C.
- connect TITANUS MICRO-SENS® to A or B and the compressed/pressed air to the remaining connection.

² Pressed air is compressed, non-purified surround air, containing humidity. Compressed air is purified and de-humidified. If TITANUS TOP-SENS® and the pipe system are located in areas below freezing, compressed air must be used for blow-through.

6.9 Steam trap




Fig. 6.12: Mounting of the steam trap to the pipe system

Install the steam trap at the lowest point in the pipe system, before the air filter and the TITANUS MICRO-SENS®. Fit the steam trap to the pipe system using the PG threaded joints.



Two 45° elbows are required on each connection end for the installation of the steam trap to the pipe system.

Connection

During installation take note of the direction of through flow (see direction arrow on the steam trap housing).

1. Prepare the pipe system with in each case two 45° angles for the connection to the steam trap and connect it to the PG threaded joints.
2. Fit the steam trap additionally with two screws and the bracket.

6.10 Test adapter




Fig. 6.13: Installing the test adapter in the pipe system

The test adapter is stuck into the pipe system immediately next to the air sampling smoke detection system. The test adapter must always be closed during normal operation and is only opened for maintenance and service purposes, to introduce test gas or smoke.



After testing detection in the air sampling smoke detection system and alarm forwarding, the test adapter must be closed again, otherwise there will be an air flow fault!

7 Commissioning



At commissioning, the test record should generally be stored in DIAG 3. This is required for later assessment of data such as the air flow figure, type of adjustment (see Chapter 7.1), commissioning temperature, air pressure and height above sea level.

7.1 Commissioning the detection unit

Before the detection unit is used, the pipe system must be installed in full, be operational and be connected to the TITANUS MICRO·SENS® device base.




Fig. 7.1: Check whether the pipe system is correctly connected

At commissioning, the TITANUS MICRO·SENS® detection unit is to be inserted in the pre-mounted device base which has been checked to ensure it is correctly wired.



When inserting the detection unit, take note of the mechanical coding which protects the device against twisting.

7.1.1 Plug and Play Commissioning

With Plug and Play commissioning the standard settings are not changed.

Air flow adjustment happens automatically when the detection unit is put in place.



If air flow adjustment is to happen automatically when the detection unit is inserted, the Jumper X4 (PIN 1,2 or PIN 2,3) must be changed.

When the TITANUS MICRO·SENS® is initialising, the green operating display flashes. When initialising is complete, the operating display changes to a permanent light.

During the initialising phase, the TITANUS MICRO·SENS® air flow should not be influenced.




Fig. 7.2: Inserting the detection unit into the device base

7.1.2 Commissioning with the diagnostics tool

If the diagnosis tool is used for commissioning, the pre-set settings can be changed.

Air flow adjustment can then be carried out in either an air pressure-dependent or an air pressure-independent manner. Air flow initialising is started using the diagnosis tool. During initialising the green operating display flashes. When initialising is complete, the operating display changes to a permanent light.

During the initialising phase, the TITANUS MICRO·SENS® air flow should not be influenced.

When commissioning is completed, a test record should be generated using the diagnosis tool.


7.2 Installing diagnostics software



If a function cannot be modified in the diagnosis tool, this is highlighted in grey. If a function is not available, the display in that particular screen is blank.

The DIAG 3 diagnosis tool is to be used for function testing. Take the following steps:

1. Install the diagnosis software on a laptop or PC¹. The operating systems can be Windows 2000 (with current service package) or XP.
2. The TITANUS MICRO·SENS® data are transferred in both directions via the infrared interface on the front of the device. The DIAG 3 interface is connected to the PC using the enclosed USB cable.
3. The diagnosis software is started via the DIAG 3 button.
4. If the DIAG 3 recognises a TITANUS MICRO·SENS®, the software goes via the current device number into the following screen.



5. The current TITANUS MICRO·SENS® data are shown on the PC screen.

¹ Laptop or PC with a USB interface



For correct colour representation, the monitor used and the graphics card must be able to show more than 256 colours.

7.3 Air flow sensor adjustment



Air flow initialising for the TITANUS MICRO·SENS® is completed successfully if a stable status for temperature and air flow is set for a period of 2 minutes. The maximum duration is 2 hours.

Air flow initialising for the TITANUS MICRO·SENS® is completed successfully if for a period of 2 minutes the following status is set:

- the temperature oscillates by less than 0.1K and
- the air flow does not oscillate too much (temperature regulation) and
- the ventilator voltage can be set properly
- ventilator and ventilator power supply working normally

The maximum duration is 2 hours.

Air flow initialising is interrupted immediately if any of the following errors occur:

- Temperature measurement defective
- Air flow measurement defective
- Ventilator control defective

Types of adjustment

- Adjustment can be conducted independently of the current air pressure. The restrictions for this kind of adjustment can be found in Chapter 4.3 "Air Flow Monitoring".
- The air flow sensor can be adjusted as a function of the current air pressure.

In order to be able to assess the air flow sensor figure correctly during maintenance work, record the type of adjustment in each case in the test records.

7.3.1 Air Pressure-Independent Adjustment

Air pressure-independent adjustment for the TITANUS MICRO·SENS® happens completely automatically each time the detection unit is inserted into the device base and the Jumper X4 is changed or via the diagnosis tool.

During the learning phase, the alarm detection is fully functional. During this time the operating display flashes and there must be no air flow influences. When initialising is completed, the operating display changes to a permanent light and the air flow sensor has determined its ideal value for the connected pipe system.

7.3.2 Air Pressure-Dependent Adjustment

This kind of adjustment can only be carried out by using the diagnostics tool.

A barometer² is required for air pressure-dependent adjustment of the air flow sensor. The following steps must be taken:

1. Press the “Settings” button so that you can change the figures in the diagnosis tool on the “Settings” screen.

2. Determine the height above sea level (NN) at the aspirating smoke detection system installation site and enter it in the “Settings” screen.
3. Using a hand-held barometer, measure the air pressure and enter this figure in the “Settings” screen in the diagnosis tool as well.



If this measured air pressure does not correspond to the annual average for that height, then the air flow sensor will not adjust to 0 %.

² Recommended: Digital precision pocket barometer GPB 1300, Greisinger electronic GmbH

TITANUS MICRO·SENS® (Date Time)

File Record Settings Device-Selection ?

Settings

Sensitivity (Fire alarm) 0,500 %/m

Alarm delay 10 s

Air flow range 50 %

Fault delay 1 min 40 s

Action alarm threshold 60 %

☐ Fault latched

☐ Dynamic air flow

☐ ROOM-IDENT

☒ LOGIC SENS

☐ Fire alarm after ROOM-IDENT

Set

Height above sea level 300 m

Air pressure 956 hPa

Fan voltage 9,0 V

Active Initialisation ☐

Initialising Standard Cancel

☐ Reception

Serial No. 00000

4. Press the "Initialise" button.

7.4 Testing the detection unit and alarm forwarding

Trigger the TITANUS MICRO·SENS® and test the transmission route to the FAS as follows:

1. Spray the test aerosol either into the first aspiration aperture or into the TITANUS MICRO·SENS® pipe system test adapter.
2. Proceed on the basis of the following table.

Check whether ...	If this is not the case ...
the alarm on the air sampling smoke detection system is displayed.	<ol style="list-style-type: none"> 1. check whether the display plate is connected. 2. there is a fault in the air sampling smoke detector. 3. change the detection unit.
the alarm is transmitted to the FAS and notified on the associated line.	<ol style="list-style-type: none"> 1. check the transmission routes.



If the **LOGIC·SENS** is set to "ON" in the "Settings" screen of the diagnosis tool (see Chapter 5.3 "Settings"), then this must be set to "OFF" for testing triggering the alarm with the test aerosol, in order to speed up alarm assessment.



Note all test data in the test record.

7.5 Testing air flow monitoring



ATTENTION

The following steps can only be taken after air flow adjustment as described in Chapter 7.3 "Air Flow Sensor Adjustment" has been carried out.

Pipe breaks

Test that a pipe break will be recognised:

1. Loosen the pipe at the connection to the TITANUS MICRO·SENS® or open the test adapter.
2. Check whether the fault display on the aspirating smoke detector is flashing.
3. Check the air flow sensor data using the DIAG 3 diagnosis tool and a PC or laptop.
4. Enter the result in the test record.

Blockage

Test that a blockage will be recognised :

1. Depending on the air flow monitoring arrangement designed in, close the corresponding number of aspiration apertures with some sticky tape.
2. Check whether the fault display on the aspirating smoke detection system is flashing.
3. Check the air flow sensor data using the DIAG 3 diagnosis tool and a PC or Laptop.
4. Enter the result in the test record.

Trouble shooting

If air flow faults are not correctly recognised by the device, proceed as follows:

Check whether ...

1. All holes are free.
2. The pipe system has any breaks or cracks.
3. All pipe connections are sealed.
4. The ventilator can blow freely.
5. The correct aspiration reducing films have been used.

If a defect is found, the functioning of the TITANUS MICRO·SENS® or the air flow sensor will be tested using a test pipe or the diagnosis software (see Chapter 7.7 "TITANUS MICRO·SENS® Function Testing").

7.6 Testing fault forwarding



ATTENTION

The following steps can only be taken after air flow adjustment as described in Chapter 7.3 "Air Flow Sensor Adjustment" has been carried out.

Test fault forwarding.

Check when testing air flow monitoring whether a fault is displayed on the TITANUS MICRO·SENS® and if applicable the FAS.

7.7 Testing the air flow sensory analysis function

If the TITANUS MICRO·SENS® cannot be adjusted, test how it is functioning by means of a test pipe, a digital precision manometer, a PC and the diagnosis tool.

Complete function testing using the digital precision manometer is described below. Limited function testing can also be carried out without the digital precision manometer.

7.7.1 Preparations for function testing

1. Release the pipe system from the TITANUS MICRO·SENS®.



After the pipe system is released from the TITANUS MICRO·SENS® and the air flow fault delay time has elapsed, it signals a fault. If no air flow fault is recognised, the device is defective.




Fig. 7.3: Checking the functioning of the TITANUS MICRO·SENS®

2. Connect the test pipe.
3. Attach the pressure measuring tube to the adapter connection B. For limited function testing without the digital precision manometer, the pressure measuring tube connection on the test pipe is to be closed.

4. Connect the PC to the TITANUS MICRO-SENS® through the diagnosis interface and start the diagnosis program.
5. In the diagnosis tool, open the "Settings" screen and set the following settings for function testing:

The image displays two screenshots of the TITANUS MICRO-SENS® diagnosis interface, specifically the 'Settings' screen. The interface is titled 'TITANUS MICRO-SENS® (Date Time)' and includes a menu bar with 'File', 'Record', 'Settings', 'Device-Selection', and '?'. The 'Settings' tab is active, showing various configuration options.

Top Screenshot: The 'Settings' screen shows the following values: Sensitivity (Fire alarm) 0,500 %/m, Alarm delay 10 s, Air flow range 30 %, Fault delay 0 min 30 s, and Action alarm threshold 60 %. On the right, there are checkboxes for 'Fault latched', 'Dynamic air flow', 'ROOM-IDENT', 'LOGIC SENS' (checked), and 'Fire alarm after ROOM-IDENT'. At the bottom, there are buttons for 'Assume', 'Standard', and 'Cancel'. A black arrow points to the 'Fault delay' field.

Bottom Screenshot: The 'Settings' screen shows the same values as the top screenshot. The 'Height above sea level' field is now 0 m, and the 'Air pressure' field is 1013 hPa. The 'Fan voltage' field is 9,0 V. The 'Active Initialisation' checkbox is checked. At the bottom, there are buttons for 'Initialising', 'Standard', and 'Cancel'. A black arrow points to the 'Height above sea level' field.

7.7.2 Carrying out function testing




After function tests are completed, the original settings must be restored. So you should record these data (e.g. using the device protocol as stored text files).

1. Close all the aspiration holes on the test pipe with some sticky tape. The negative pressure generated by the TITANUS MICRO·SENS® must, after a short running time, be 80 Pa. For limited function testing without the digital precision manometer, this step is omitted.



After the aspiration holes are closed, within 30 secs the device signals the faults "Detection unit defective" and "Air flow too low (statistical evaluation)".



2. Release the 4.6 mm and the 4.2 mm aspiration holes on the test pipe again.
3. Now click on the lower "Set" button in the "Settings" screen and start air flow initialising by pressing the "Initialise" button. The fault messages and displays must go out. The "Initialising active" field in the "Settings" screen of the diagnosis tool flashes for the duration of initialising.

4. After initialising, close the 4.2 mm aspiration hole on the test pipe with some sticky tape. After about 5 secs, the fault display on the device must start to flash. After about 35 secs, the fault display on the device must be permanently on. The device signals the fault "Air flow too low (statistical evaluation)". The air flow figure is about -35 %.
5. Open the 4.2 mm aspiration hole again. After a few seconds, the fault display on the TITANUS MICRO·SENS® must stop flashing.
6. Open the 7.0 mm aspiration pipe on the test pipe. After about 5 secs the fault display on the device must start to flash. After about 35 secs, the fault display on the device must be permanently on. The device signals the fault "Air flow too high (statistical evaluation)". The air flow figure is about +85 %.
7. Close the 7.0 mm aspiration hole again. The fault display on the TITANUS MICRO·SENS® must stop flashing after a few seconds.
8. Remove the test pipe and re-connect the pipe system.

After function tests are completed, the original settings must be restored. Commissioning the TITANUS MICRO·SENS® is to be repeated from Chapter 7.3 "Air Flow Sensor Adjustment".

Connection testing Test whether ...

1. The pipe system is firmly connected to the TITANUS MICRO·SENS® pipe connection.
2. All pipe fittings are glued and the pipe system is sealed tight. For this, first close all aspiration apertures (e.g. with insulating tape). Using a flow measurement device, measure the air flow at the aperture for the air flow return.
3. The correct aspiration reducing films have been stuck to the aspiration apertures.



After the air flow sensor is adjusted (Chapter 7.3 "Air Flow Sensor Adjustment ") no more changes should be made to the pipe system. If changes are necessary later, the air flow sensor must be adjusted again.


After function tests are completed, the device and the pipe system must be re-commissioned from Chapter 7.3 "Air Flow Sensor Adjustment".



After commissioning is completed, the settings should be recorded using the diagnosis tool and stored. A print-out of the settings should be filed with the project documents for subsequent follow-up work.

7.8 Commissioning fire seat location

Locating the seating of a fire is undertaken using the diagnosis tool in the „ROOM-IDENT“ screen.



The Learn button opens the view with figures which can be set for determining the transport times for locating fire at the areas A –E (see next screen).



Commissioning for localisation is the same procedure for « Fire alarm after ROOM·IDENT » and « ROOM·IDENT ».

First the number of aspiration apertures then the blow through time and blow through and aspiration ventilator voltage must be entered.

Click on the question mark for help.

? Blow through time help

Blow through time (for blow through ventilator voltage 13.5 V)

During blow through time the smoke is blown backwards out of the pipe. The blow through time can be selected from the following table (intermediate values = next largest value):

Pipe Length (m)	Time (secs)
10	80
15	97
20	113
25	130
30	147
35	163
40	180

1 second should be added to the blow through time for each pipe bend or angle.

? Blow through ventilator

The operating voltage for the blow through ventilator should if possible be kept at 13.5V for location. It can be changed as follows for special applications:

Operating Status	Voltage (V)
- for an optimum (short) blow through time	13.5 V
- for longer blow through times - for lower voltage drops with smaller cable cross-sections	9.0 – 13.4 V

The value selected is stored permanently in the TITANUS MICRO-SENS® and used for each location procedure.

Attention: Under certain circumstance the blow through time may not be sufficient to blow through the pipe, if too low a blow through ventilator voltage was selected. This can cause a false fire site to be displayed.

? Aspiration ventilator help

The operating voltage for the aspiration ventilator must be selected so that a time difference of about 2 to 4 seconds between two neighbouring aspiration apertures is not undercut. If the time differences are too short, then when there is an alarm, a false fire location may be displayed. As the air flow between aperture A and B is the highest, then with a normal design this has the shortest time.

The following table contains guideline figures for setting the operating voltage:

Distance A - B (m)	Max. Voltage (V)
3	9.0
4	9.8
5	10.7
6	11.5
7	12.4
from 8 m	13.2

The aspiration point for which the transport time is to be determined is now selected by clicking. For each aspiration point selected, the pre-selected time required for reaching the aspiration point and providing the smoke must be entered. When the pre-selected time has lapsed, the particular smoke detection point must be charged with smoke. There must be smoke at the aspiration point for another 10 to 15 seconds after the pre-selected time has lapsed.

Before starting to determine the transport time, check by using a bar graph (smoke level) that there is no smoke in the aspiration pipe.

After starting to determine the transport time, the learn mode is active and TITANUS MICRO-SENS® switches to blowing out the aspiration pipe. The display for the aspiration point in question is yellow.

After the pre-selected time has lapsed, the TITANUS MICRO-SENS® switches to aspirate. At this point, there must be smoke at the aspiration point selected.


If the TITANUS MICRO-SENS® detects the smoke, the smoke level indicates this. The display for the aspiration point selected goes green and the time determined is entered.

The learn mode for the aspiration point selected is thereby closed.

7.9 Commissioning the reaction indicators

An indicator is selected in the “ROOM-IDENT” screen for testing the address setting for the reaction indicators during commissioning. You can then test whether the right reaction indicator is lit up and as set is either flashing or on permanently.

Before quitting the “ROOM-IDENT” screen, the reaction indicator selection must be set to “Off” and “Current Setting” must also be at “Off”.



8 Maintenance

8.1 Visual check

Check whether ...

- when the pipe system is freely accessible it is firmly mounted and undamaged.
- the aspiration apertures on the pipe system are free.
- aspiration pipe and connection cable are firmly connected.
- the TITANUS MICRO·SENS® is undamaged.

8.2 Testing detector and alarm forwarding

Proceed as described in Chapter 7.4 "Detection Unit and Alarm Forwarding". Also check the detection unit visually for external dirt or damage and if necessary make replacements.



A hardware error on the detection unit is displayed in the "Messages" screen of the diagnosis tool.

8.3 Testing pipe system

Test the aspiration apertures on the pipe system for blockage, in areas in which dust particles or icing may be found. If necessary, blow the pipe system and aspiration apertures free with compressed air. Use a portable compressed air bottle to do this (blow through device) or press the manual blow through equipment installed on site.



Before blowing through the pipe system, separate the TITANUS MICRO·SENS® from the pipe system, as otherwise the air flow sensor will be damaged.

8.4 Exchanging the detection unit




Fig. 8.3: Exchanging the detection unit

- ❶ With the aid of a screwdriver, loosen the four screws on the detection unit and remove it from the device base.
- ❷ When inserting the new detection unit, note the mechanical coding, this protects the device against twisting. Change the jumper X4.
- ❸ Now with the aid of a screwdriver, screw the four screws on the detection unit down firmly again.
- ❹ The device initialises automatically when the jumper X4 is changed.

8.5 Exchanging the type AF-TM air filter for the device base




Fig. 8.4: Exchanging the type AF-HBTM air filter in the TITANUS MICRO·SENS® device base

- ❶ With the aid of a screwdriver, loosen the four screws on the detection unit and remove it from the device base.
- ❷ Pull both filter mountings out of the device base and remove the filter inserts. Conduct a visual check for dirt and if necessary change the filters. Then replace the filter mounting.
- ❸ Now with the aid of a screwdriver screw the four screws on the detection unit down again firmly.
- ❹ The device initialises automatically when the jumper X4 is changed.

8.6 Changing the filter on the LF-AD-x air filter




Fig. 8.5: Changing the filter Inserts

To clean or change the filter inserts, proceed as follows:

- ❶ Loosen the four screws and remove the housing cover.
- ❷ Remove the filter inserts and check them visually for dust. If slightly dirty, the filter inserts can be cleaned. If they are very dirty, they must be changed.
- ❸ Clean the housing inner carefully of all dust deposits. Now insert the cleaned or new filter inserts in the correct order. The correct sequence is shown on the information plate on the housing base.
- ❹ Replace the housing cover and screw it down again.



When used where there is mainly fine dust, three optional fine dust filters can be used.



Opening the device cover on the LF-AD air filter on the TITANUS MICRO·SENS® can lead to an air flow fault.

8.7 Changing the filter on the SF-400/650 special filter




Fig. 8.6: Changing the filter element

To change the filter element, proceed as follows:

- ❶ Loosen the two PVC transition threaded joints on the special filter ❶a and remove it ❶b.
- ❷ Loosen both screwed plugs on the filter housing.
- ❸ Remove the old filter element. Put the new filter element into the filter housing.
- ❹ Screw both screwed plugs to the filter housing.
- ❺ Replace the special filter in the pipe system and fix it with the PVC transition threaded joints.



When the special filter is being installed, pay attention to the throughflow direction!



Opening the special filter will produce an air flow fault on the TITANUS MICRO·SENS®.

8.8 Pipe system blow through process




Fig. 8.7: Lever position on the ball valve

The pipe system manual blow through process should be conducted in the following stages:

1. Connect the compressed air supply needed for free-blowing the pipe system (compressor or mobile free-blow device) via the quick release coupling muff to the 3-way muff ball valve on the pipe system to be blown through.
2. Separate the pipe system to be blown through by the 3-way muff ball valve from the corresponding device, by moving the ball valve lever from the 0° operating position to the 180° position (see Fig. 8.7).
3. Blow the pipe system free manually for about 10 seconds.
4. Put the ball valve lever into the 90° position. In this position, the device cannot be connected either to the pipe system or the compressed or pressed air supply connection. Wait about 20 seconds so that the dust and dirt stirred up in the pipe system can settle and thus not be aspirated via the air sampling smoke detection system.
5. Re-connect the free-blown pipe system to the corresponding device within 10 seconds by setting the ball valve back to the 0° position.

8.9 Checking the air flow sensor adjustment

Test the air flow sensor value using the diagnosis software.

Operating principle

Whilst the connected pipe system is initialising, the device first stores the measured actual value of the air flow as an ideal value, via integrated air flow monitoring. This ideal value thereafter serves as the reference value for further evaluation of any air flow fault. Depending on the air flow threshold selected (see Chapter 4.3, section on Adjusting Air Flow Sensitivity), the current air flow value can oscillate more or less around this ideal value during operating, without triggering an air flow fault. Only if the air flow threshold selected is exceeded is the air flow fault signalled by the device and can thus be forwarded.

Checking the actual value The tolerance range for the air flow threshold selected as well as the actual and ideal values are shown in the diagnosis software. The limits correspond to the air flow range set.

Check the deviation of the actual value from the ideal value. If it deviates by $> \pm 3/4$ from the set threshold, you should test the pipe system as a precaution (on this, see section "Clearing Air Flow Fault", next page).



The current air flow value cannot deviate from the ideal value just because of a fault in the pipe system (break or blockage) but also because of air pressure oscillations in the environment.

air pressure-dependent

To ensure that the device operates long-term without faults, the air flow sensor must be adjusted to be air pressure-dependent (see Chapter 7.3.2). It is only with this type of adjustment that small air pressure oscillations lie within the monitoring window and thus within the permitted tolerance range.



If the air flow change has been set at less than 30 %, there **must** be air pressure-dependent adjustment.

air pressure-independent

If the sensor adjustment is air pressure-independent, oscillations in the air pressure can lead to undesirable air flow faults. At more than 30 % air flow change the air flow sensor adjustment must be air pressure-independent and it must be ensured that no oscillations in air pressure can occur in the surrounding environment.



If it cannot be ensured that no oscillations in air pressure will occur in the surrounding environment, the air flow sensor must definitely be air pressure-dependent adjusted.

**Clearing an
air flow fault**

If air flow adjustment was conducted as air pressure-dependent and the actual value is still no longer within the tolerance range for the air flow threshold selected (air flow fault signalled by the device), then there must be another fault variable apart from any air pressure or temperature oscillation.

1. In this case, test that the pipe system is sealed tight and not blocked (see Chapter 7.5).



If during fault location the pipe network was changed, the original pipe system configuration must be restored after fault location is completed and the air flow again adjusted.

2. If this test does not show any defects, check air flow monitoring by connecting the test pipe and carrying out the function test described in Chapter 7.7.2.



If there is a defect in air flow monitoring, only authorised personnel may change the detection unit!

If the function test shows no deviations from the described procedure, it is certain that there is no defect in air flow monitoring.

3. Adjust again with the pipe system connected.



You must record the type of adjustment (air pressure-dependent or air pressure-independent) and possibly the figures for air pressure, height above sea level and voltage set, in the testing records.

4. Note the current air flow value during this maintenance session or check it at the latest at the next inspection.



With the aid of the diagnosis software, all stored and current device data and the settings input using the diagnosis tool can be stored as files.

5. If there is a similar ideal value deviation as before, interfering environmental influences are the cause of this deviation. If these negative influences cannot be stopped from affecting air flow monitoring, the air flow range must be increased.

8.10 Testing fire seat location and the reaction indicators

Testing fire seat location and the reaction indicators.

The screenshot displays the 'ROOM-IDENT' interface of the TITANUS MICRO·SENS® device. The interface includes a menu bar at the top with options: File, Record, Settings, Device-Selection, and a help icon (?). Below the menu bar are tabs for Status, Fault messages, Settings, and ROOM-IDENT (which is currently selected). The main area of the screen is divided into several sections. On the left, there is a 'Smoke level' indicator with a vertical scale from 0 to 10. In the center, there is a vertical list of points labeled A, B, C, D, and E, each with an input field for time in seconds (s). On the right, there is a 'Test external indicators' section with a dropdown menu for 'Indicator selection' (currently set to 'Off') and a 'Current setting' field (currently set to 'Off'). Below this, there is a 'Pre selection time' field set to 1 min 0 s. There are buttons for 'Establish seat of fire' (labeled 'Start'), 'Measuring active' (with a checkbox), and 'Test mode active' (with a checkbox). At the bottom of the screen, there is a 'Cancel' button, a status bar with two indicators: 'Seat of fire not established' (white box) and 'Seat of fire established' (red box), a 'Reception' checkbox, and a 'Serial No.' field set to 00000.

At the first location screen "ROOM-IDENT"(see first figure in chapter 7.8) the button "test" needs to be prened in order to open this screen.

To test, select the "Pre selection time" and then click on Start to determine the seat of fire.

The TITANUS MICRO·SENS® switches to blowing out the aspiration pipe.

The particular aspiration point must be charged with smoke until the pre-selected time has elapsed. There must still be smoke at the aspiration point for 10 to 15 seconds after the pre-selected time has expired.

After the pre-selected time has elapsed, the TITANUS MICRO·SENS® switches to aspiration and the time measured until the smoke is detected determines the aspiration point. Check whether it is the right aspiration point.

8.11 Testing Air Flow Monitoring

A break or a blockage in a pipe is displayed on the diagnosis tool "Message" screen.

Test air flow monitoring in accordance with the instructions described in Chapter 7.5 "Air Flow Monitoring".

8.12 Testing Fault Forwarding

A fault is displayed on the TITANUS MICRO·SENS® and possibly on the FAS.

Proceed as described in Chapter 7.6 "Fault Forwarding".

8.13 Maintenance Intervals

Maintenance includes regular inspections and servicing. The air sampling smoke detection systems are first checked at commissioning and then quarterly if not specified different by the national regulations. Further checks are to be conducted at every 4th check, resulting in the following split:

- quarterly check **Inspection**
- annual check **Servicing + 4th annual inspection**

Type of Check	Measure	Other Information in Chapter
Inspection	Visual check	8.1
	Detection unit and alarm forwarding	8.2
	Check pipe system	8.3
	Air flow sensor adjustment	8.9
	Fault forwarding	7.6
Servicing + 4 th annual inspection	Visual check	8.1
	Detection unit and alarm forwarding	8.2
	Check pipe system	8.3
	Air flow sensor adjustment	8.9
	Air flow monitoring	7.5
	Fault forwarding	7.6

Appendix

Projection Tables

System Product List

Certificate of Approval of Components and Systems

EMC Declaration of Conformity

Inspection Protocol

Glossary

Conformity certification pursuant to EU

Projection without filter

Type	Sensitivity (% Lt/m)	Number of points							
		1	2	3	4	5	6	7	8
DM-TM-10	0,1	A	A	A	A	A	A	A	A
	0,2	A	A	A	A	A	A	B	B
	0,3	A	A	A	A	B	B	B	B
	0,4	A	A	A	B	B	B	B	C
DM-TM-50	0,5	A	A	B	B	B	B	C	C
	0,6	A	A	B	B	B	C	C	C
	0,7	A	B	B	B	C	C	C	C
	0,8	A	B	B	C	C	C	C	C
	0,9	A	B	B	C	C	C	C	C
	1	A	B	B	C	C	C	C	C
	1,1	A	B	C	C	C	C	C	C
	1,2	A	B	C	C	C	C	C	C
	1,3	B	B	C	C	C	C	C	
	1,4	B	B	C	C	C	C		
	1,5	B	B	C	C	C	C		
	1,6	B	C	C	C	C	C		
	1,7	B	C	C	C	C			
	1,8	B	C	C	C	C			
	1,9	B	C	C	C	C			
	2	B	C	C	C				

without pipe accessories or with detector box or VSK

Pipe shape	$U_{Fan}[V]$	1	2	3	4	5	6	7	8	permitted total pipe length [m]
I	≥ 9	40	40	40	40	40				
U	≥ 9	50	50	50	50	50	50	50	50	
M	≥ 9	50	50	50	50	50	50	50	50	
Double U	≥ 9	50	50	50	50	50	50	50	50	

with OXY-SENS and detector box or with steam trap or with VSK and detector box

Pipe shape	$U_{Fan}[V]$	1	2	3	4	5	6	7	8	permitted total pipe length [m]
I	≥ 9	40	40	40						
U	≥ 9	50	50	50	50	50	50			
M	≥ 9	50	50	50	50	50	50			
Double U	≥ 9	50	50	50	50	50	50	50	50	

Projection with air filter LF-AD

Type	Sensitivity (% Lt/m)	Number of points							
		1	2	3	4	5	6	7	8
DM-TM-10	0,1	A	A	A	A	A	A	A	A
	0,2	A	A	A	A	A	B	B	B
	0,3	A	A	A	B	B	B	B	B
	0,4	A	A	B	B	B	B	C	C
	0,5	A	A	B	B	B	C	C	C
	0,6	A	B	B	B	C	C	C	C
	0,7	A	B	B	C	C	C	C	C
	0,8	A	B	B	C	C	C	C	C
	0,9	A	B	C	C	C	C	C	C
	1	A	B	C	C	C	C	C	C
	1,1	B	B	C	C	C	C	C	
	1,2	B	B	C	C	C	C		
	1,3	B	C	C	C	C	C		
	1,4	B	C	C	C	C			
	1,5	B	C	C	C	C			
	1,6	B	C	C	C	C			
	1,7	B	C	C	C				
	1,8	B	C	C	C				
	1,9	B	C	C	C				
	2	B	C	C	C				

without additional pipe accessories or with detector box or VSK

Pipe shape	$U_{Fan}[V]$	1	2	3	4	5	6	7	8	permitted total pipe length [m]
I	≥ 9	40	40	40	40	40				
U	≥ 9	50	50	50	50	50	50	50	50	
M	≥ 9	50	50	50	50	50	50	50	50	
Double U	≥ 9	50	50	50	50	50	50	50	50	

with OXY-SENS and detector box or with steam trap or with VSK and detector box

Pipe shape	$U_{Fan}[V]$	1	2	3	4	5	6	7	8	permitted total pipe length [m]
I	≥ 9	40	40	40						
U	≥ 9	50	50	50	50	50	50			
M	≥ 9	50	50	50	50	50	50			
Double U	≥ 9	50	50	50	50	50	50	50	50	

Projection with air filter LF-AD -1

Type	Sensitivity (% Lt/m)	Number of points							
		1	2	3	4	5	6	7	8
DM-TM-10	0,1	A	A	A	A	A	A	A	A
	0,2	A	A	A	A	B	B	B	B
	0,3	A	A	A	B	B	B	B	B
	0,4	A	A	B	B	B	B	C	C
DM-TM-50	0,5	A	B	B	B	C	C	C	C
	0,6	A	B	B	B	C	C	C	C
	0,7	A	B	B	C	C	C	C	C
	0,8	A	B	B	C	C	C	C	C
	0,9	A	B	C	C	C	C	C	C
	1	B	B	C	C	C	C	C	
	1,1	B	B	C	C	C	C	C	
	1,2	B	B	C	C	C	C		
	1,3	B	C	C	C	C	C		
	1,4	B	C	C	C	C			
	1,5	B	C	C	C	C			
	1,6	B	C	C	C				
	1,7	B	C	C	C				
	1,8	B	C	C	C				
	1,9	B	C	C	C				
	2	B	C	C					

without additional pipe accessories or with detector box

Pipe shape	$U_{Fan}[V]$	1	2	3	4	5	6	7	8	permitted total pipe length [m]
I	≥ 9	40	40	40	40	40				
U	≥ 9	50	50	50	50	50	50	50	50	
M	≥ 9	50	50	50	50	50	50	50	50	
Double U	≥ 9	50	50	50	50	50	50	50	50	

with OXY-SENS and detector box or with steam trap or with VSK and/or detector box

Pipe shape	$U_{Fan}[V]$	1	2	3	4	5	6	7	8	permitted total pipe length [m]
I	≥ 9	40	40	40						
U	≥ 9	50	50	50	50	50	50			
M	≥ 9	50	50	50	50	50	50			
Double U	≥ 9	50	50	50	50	50	50	50	50	

Projection with air filter LF-AD-2

Type	Sensitivity (% Lt/m)	Number of points							
		1	2	3	4	5	6	7	8
DM-TM-10	0,1	A	A	A	A	A	A	A	A
	0,2	A	A	A	A	B	B	B	B
	0,3	A	A	B	B	B	B	C	C
	0,4	A	A	B	B	B	C	C	C
DM-TM-50	0,5	A	B	B	B	C	C	C	C
	0,6	A	B	B	C	C	C	C	C
	0,7	A	B	C	C	C	C	C	C
	0,8	A	B	C	C	C	C	C	C
	0,9	B	B	C	C	C	C	C	
	1	B	B	C	C	C	C		
	1,1	B	C	C	C	C	C		
	1,2	B	C	C	C	C			
	1,3	B	C	C	C	C			
	1,4	B	C	C	C				
	1,5	B	C	C	C				
	1,6	B	C	C	C				
	1,7	B	C	C					
	1,8	B	C	C					
	1,9	B	C	C					
	2	B	C	C					

without additional pipe accessories or with detector box

Pipe shape	$U_{Fan}[V]$	1	2	3	4	5	6	7	8	permitted total pipe length [m]
I	≥ 9	40	40	40	40	40				
U	≥ 9	50	50	50	50	50	50	50	50	
M	≥ 9	50	50	50	50	50	50	50	50	
Double U	≥ 9	50	50	50	50	50	50	50	50	

with OXY-SENS and detector box or with steam trap or with VSK and detector box

Pipe shape	$U_{Fan}[V]$	1	2	3	4	5	6	7	8	permitted total pipe length [m]
I	≥ 9	40	40	40						
U	≥ 9	50	50	50	50	50	50			
M	≥ 9	50	50	50	50	50	50			
Double U	≥ 9	50	50	50	50	50	50	50	50	

Projection with SF-400 / SF-650

Type	Sensitivity (% Lt/m)	Number of points							
		1	2	3	4	5	6	7	8
DM-TM-10	0,1	A	B	B	B	C	C	C	C
	0,2	B	B	C	C	C	C		
	0,3	B	C	C	C				
	0,4	B	C	C					
DM-TM-50	0,5	C	C						
	0,6	C	C						
	0,7	C							
	0,8	C							
	0,9	C							
	1	C							
	1,1	C							
	1,2	C							
	1,3	C							
	1,4								
	1,5								
	1,6								
	1,7								
	1,8								
	1,9								
	2								

without additional pipe accessories

Pipe shape	$U_{Fan}[V]$	1	2	3	4	5	6	7	8	permitted total pipe length [m]
I	≥ 9	40	40	40	40					
U	≥ 9	50	50	50	50	50	50			
M	≥ 9	50	50	50	50	50	50			
Double U	≥ 9	50	50	50	50	50	50	50	50	

with detector box and/or VSK

Pipe shape	$U_{Fan}[V]$	1	2	3	4	5	6	7	8	permitted total pipe length [m]
I	≥ 9	40	40	40						
U	≥ 9	50	50	50	50	50	50			
M	≥ 9	50	50	50	50	50	50			
Double U	≥ 9	50	50	50	50	50	50	50	50	

TITANUS MICRO-SENS, DNL-Delivery Transaction

--

order no.	description	unit
Air Sampling Smoke Detection Systems		
AD-05-1500	detector box insert TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-MB-TM-10	
<2> <>		
AD-05-1510	detector box insert TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-MB-TM-B-10	
<2> <>		
AD-05-1520	detector box insert TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-MB-TM-50	
<2> <>		
AD-05-1530	detector box insert TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-MB-TM-B-50	
<2> <>		
AD-05-3500	device base TITANUS MICRO-SENS	pc.
<P> <Z>	type HB-TM	
<2> <>		
AD-05-4000	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-10	
<2> <>		
AD-05-4010	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-R-10	
<2> <>		
AD-05-4020	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-B-10	
<2> <>		
AD-05-4030	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-RB-10	
<2> <>		
AD-05-4040	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-Z-10	
<2> <>		
AD-05-4050	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-ZB-10	
<2> <>		

<0>=Generic purch. item, <1>=Purch. item fixed vendor, <2>=Proprietary develop. (ANT/develop.), <3>=in-house prod. (ANT/develop./prod.), <4>=Compon. 140I FI.
<AM>=discontinued model, <Z> = approved, <P>=compulsory purchase, purchase only via WAGNER head office, <L>=compulsory supplier, purchase via fixed supplier

TITANUS MICRO-SENS, DNL-Delivery Transaction

--

order no.	description	unit
AD-05-4100	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-10-F	
<2> <>		
AD-05-4120	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-B-10-F	
<2> <>		
AD-05-4300	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-50	
<2> <>		
AD-05-4310	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-R-50	
<2> <>		
AD-05-4320	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-B-50	
<2> <>		
AD-05-4330	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-RB-50	
<2> <>		
AD-05-4340	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-Z-50	
<2> <>		
AD-05-4350	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-ZB-50	
<2> <>		
AD-05-4500	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-50-F	
<2> <>		
AD-05-4520	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-B-50-F	
<2> <>		
AD-05-4521	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-10	
<2> <>		

<0>=Generic purch. item, <1>=Purch. item fixed vendor, <2>=Proprietary develop. (ANT/develop.), <3>=in-house prod. (ANT/develop./prod.), <4>=Compon. 140l FI.
<AM>=discontinued model, <Z> = approved, <P>=compulsory purchase, purchase only via WAGNER head office, <L>=compulsory supplier, purchase via fixed supplier

TITANUS MICRO-SENS, DNL-Delivery Transaction

--

order no.	description	unit
AD-05-4522	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-R-10	
<2> <>		
AD-05-4524	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-B-10	
<2> <>		
AD-05-4525	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-RB-10	
<2> <>		
AD-05-4527	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-Z-10	
<2> <>		
AD-05-4528	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-ZB-10	
<2> <>		
AD-05-4529	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-10-F	
<2> <>		
AD-05-4530	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-B-10-F	
<2> <>		
AD-05-4531	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-50	
<2> <>		
AD-05-4532	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-R-50	
<2> <>		
AD-05-4534	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-B-50	
<2> <>		
AD-05-4535	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-RB-50	
<2> <>		

<0>=Generic purch. item, <1>=Purch. item fixed vendor, <2>=Proprietary develop. (ANT/develop.), <3>=in-house prod. (ANT/develop./prod.), <4>=Compon. 140l FI.
<AM>=discontinued model, <Z> = approved, <P>=compulsory purchase, purchase only via WAGNER head office, <L>=compulsory supplier, purchase via fixed supplier

TITANUS MICRO-SENS, DNL-Delivery Transaction

--

order no.	description	unit
AD-05-4537	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-Z-50	
<2> <>		
AD-05-4538	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-ZB-50	
<2> <>		
AD-05-4539	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-50-F	
<2> <>		
AD-05-4540	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TMV-B-50-F	
<2> <>		

TITANUS MICRO-SENS, DNL-Delivery Transaction

--

order no.	description	unit
Front Film Sheets		
AD-10-1400	front film sheet TITANUS MICRO-SENS	pc.
<P> <Z>	type FW-TM	
<2> <>		
AD-10-1410	front film sheet TITANUS MICRO-SENS	pc.
<P> <Z>	type FW-TM-R	
<2> <>		
AD-10-1420	front film sheet TITANUS MICRO-SENS	pc.
<P> <Z>	type FW-TM-B	
<2> <>		
AD-10-1430	front film sheet TITANUS MICRO-SENS	pc.
<P> <Z>	type FW-TM-RB	
<2> <>		
AD-10-1440	front film sheet TITANUS MICRO-SENS	pc.
<P> <Z>	type FW-TMV	
<2> <>		
AD-10-1450	front film sheet TITANUS MICRO-SENS	pc.
<P> <Z>	type FW-TMV-R	
<2> <>		
AD-10-1460	front film sheet TITANUS MICRO-SENS	pc.
<P> <Z>	type FW-TMV-B	
<2> <>		
AD-10-1470	front film sheet TITANUS MICRO-SENS	pc.
<P> <Z>	type FW-TMV-RB	
<2> <>		
AD-10-1500	front film sheet TITANUS MICRO-SENS	pc.
<P> <Z>	type FW-AB-1	
<2> <>		

<0>=Generic purch. item, <1>=Purch. item fixed vendor, <2>=Proprietary develop. (ANT/develop.), <3>=in-house prod. (ANT/develop./prod.), <4>=Compon. 140I FI.
<AM>=discontinued model, <Z> = approved, <P>=compulsory purchase, purchase only via WAGNER head office, <L>=compulsory supplier, purchase via fixed supplier

TITANUS MICRO-SENS, DNL-Delivery Transaction

--

order no.	description	unit
Accessories		
02-60-0640	push button	pc.
<P> <Z>	type R13-527A	
<0> <>		
09-20-5481	reset board	pc.
<P> <Z>	type E548/c	
<2> <>		
09-20-6100	GSM module TITANUS	pc.
<P> <Z>	type GU-1	
<2> <>		
09-20-6140	network module TITANUS	pc.
<P> <Z>	type NU-2	
<2> <>		
09-20-6680	TITANUS relay module	pc.
<P> <Z>	type RU-1	
<2> <>		
09-20-6681	TITANUS relay module	pc.
<P> <Z>	type RU-2	
<2> <>		
AD-05-0563	diagnostic tool	pc.
<P> <Z>	type DIAG 3/a	
<2> <>		
AD-05-0580	test unit for device base	pc.
<P> <Z>	type DIAG-Con	
<2> <>		
AD-05-0590	smoke pen	pc.
<P> <Z>	type CT-1	
<0> <>		
AD-05-0595	holding device for smoke pen	pc.
<P> <Z>	type AK-CT-1	
<0> <>		
AD-05-0597	smoke candles for smoke pen	pc.
<P> <Z>	type SP-CT-1 (set = 6 candles)	
<0> <>		

<0>=Generic purch. item, <1>=Purch. item fixed vendor, <2>=Proprietary develop. (ANT/develop.), <3>=in-house prod. (ANT/develop./prod.), <4>=Compon. 140l FI.
<AM>=discontinued model, <Z> = approved, <P>=compulsory purchase, purchase only via WAGNER head office, <L>=compulsory supplier, purchase via fixed supplier

TITANUS MICRO-SENS, DNL-Delivery Transaction

--

order no.	description	unit
AD-05-0930	cable glands	pc.
<P> <Z>	type M20-MS (PU=100 Pcs.)	
<0> <>		
AD-05-0940	cable glands	pc.
<P> <Z>	type M25-MS (PU=100 Pcs.)	
<0> <>		
AD-05-0950	cable glands	pc.
<P> <Z>	type M20 (PU=100 pcs.)	
<0> <>		
AD-05-0955	cable glands	pc.
<P> <Z>	type M25 (PU=100 pcs.)	
<0> <>		
AD-05-0960	screwable cable glands	pc.
<P> <Z>	type Snaptec M20 (PU=50 pcs.)	
<0> <>		
AD-05-0970	screwable cable glands	pc.
<P> <Z>	type Snaptec M25 (PU=50 pcs.)	
<0> <>		
AD-05-2100	parallel display TITANUS MICRO-SENS	pc.
<P> <Z>	type RD-TM	
<2> <>		
AD-05-5200	housing for TITANUS accessories	pc.
<P> <Z>	type AB-1	
<2> <>		
AD-10-0550	test pipe for air sampling systems	pc.
<P> <Z>	type DIAG-Pipe	
<0> <>		
BM-05-1705	double input module "AnalogPlus"	pc.
<P> <Z>	type DC 1131-31	
<2> <>		
BM-05-1750	input module "Interactive"	pc.
<P> <Z>	type DC 1157-AA, VdS-no.: G 299 031	
<1> <>		

<0>=Generic purch. item, <1>=Purch. item fixed vendor, <2>=Proprietary develop. (ANT/develop.), <3>=in-house prod. (ANT/develop./prod.), <4>=Compon. 140I FI.
<AM>=discontinued model, <Z> = approved, <P>=compulsory purchase, purchase only via WAGNER head office, <L>=compulsory supplier, purchase via fixed supplier

TITANUS MICRO-SENS, DNL-Delivery Transaction

--

order no.	description	unit
Spare Parts		
09-20-6500	display board	pc.
<P> <Z>	type DB-TM	
<3> <>		
09-20-6550	indicator bus adapter	pc.
<P> <Z>	type IA-TM	
<3> <>		
10-60-0695	operat.device reset and discon. button	pc.
<P> <Z>	type RTT-1, 19"	
<2> <>		
AD-05-0570	transport case for diagnostic tool	pc.
<P> <Z>	type DIAG-Case	
<0> <>		
AD-05-0575	adapter cable for diagnostic interface	pc.
<P> <Z>	type AC-DIAG 3	
<0> <>		
AD-05-0578	connecting cable f. diagnostic interface	pc.
<P> <Z>	type CC-DIAG 3	
<0> <>		
AD-05-0628	diagnostic interface	pc.
<P> <Z>	type IF-DIAG 3	
<2> <>		
AD-05-0630	board for reset and disconnecting button	pc.
<P> <Z>	type RTT-1	
<2> <>		
AD-05-0635	holding device for diagnostic interface	pc.
<P> <Z>	type DIAG 3-Clip/a	
<0> <>		
AD-05-0637	holding device for diagnostic interface	pc.
<P> <Z>	type DB-DIAG 3-TM	
<0> <>		
AD-05-0639	holding device for diagnostic interface	pc.
<P> <Z>	type DB-DIAG 3-TR	
<0> <>		

<0>=Generic purch. item, <1>=Purch. item fixed vendor, <2>=Proprietary develop. (ANT/develop.), <3>=in-house prod. (ANT/develop./prod.), <4>=Compon. 140I FI.
<AM>=discontinued model, <Z> = approved, <P>=compulsory purchase, purchase only via WAGNER head office, <L>=compulsory supplier, purchase via fixed supplier

TITANUS MICRO-SENS, DNL-Delivery Transaction

--

order no.	description	unit
AD-05-3550	replacement parts for device base	pc.
<P> <Z>	type SP-TM-1	
<0> <>		
AD-05-3560	lid screws	pc.
<P> <Z>	type SP-TM-3 (PU=10 pcs.)	
<0> <>		
AD-05-3570	jumper for the air flow initialisation	pc.
<P> <Z>	type SP-TM-2 (PU=10 pcs.)	
<0> <>		
AD-05-3580	air filter for TITANUS MICRO-SENS	pc.
<P> <Z>	type SP-TM-5 (PU=10 pcs.)	
<0> <>		
AD-05-4400	set of seals for the detection unit	pc.
<P> <Z>	type SP-TM-4	
<0> <>		

TITANUS MICRO-SENS, DNL-Delivery Transaction

--

order no.	description	unit
-----------	-------------	------

Phase-out

AD-05-0560	diagnostic tool	pc.
<P> <Z>	type DIAG 3	
<2> <AM>		
AD-05-4315	detection unit TITANUS MICRO-SENS	pc.
<P> <Z>	type DM-TM-R-50/a	
<2> <AM>		

<0>=Generic purch. item, <1>=Purch. item fixed vendor, <2>=Proprietary develop. (ANT/develop.), <3>=in-house prod. (ANT/develop./prod.), <4>=Compon. 140l FI.
<AM>=discontinued model, <Z> = approved, <P>=compulsory purchase, purchase only via WAGNER head office, <L>=compulsory supplier, purchase via fixed supplier



Certificate

of Approval of Components and Systems

Holder of the Approval:

WAGNER Group GmbH
Schleswigstraße 1 - 5
DE-30853 Longenhagen

Approval No.:	No. of pages:	Valid from:	Valid to:
G 206004	39	01.07.2009	30.06.2013

Subject matter of the Approval:

Aspirating Smoke Detectors
Type TITANUS MICRO·SENS®; TITANUS RACK·SENS®

Use:

in Automatic Fire Detection and Fire Alarm Systems

Basis for approval:

DIN EN 54-20 (02/09) - Aspirating Smoke Detectors
DIN EN 54-17 (03/06) - Short Circuit Isolators
VdS 2344 (12/05) - Procedure Guidelines

Köln (Cologne), 01.07.2009

Schüngel

Managing Director

ppa. Stahl

Head of the VdS Certification Body



DAT-ZE 005/92

VdS Schadenverhütung GmbH
Zertifizierungsstelle
Amsterdamer Str. 174
D-50735 Köln

A company of the German
Insurance Association (GDV)
(German federation of insurance
companies)

Accredited by the "Deutsche
Akkreditierungsstelle Technik
(DATech)" as a certification body
for the areas of fire protection
and security



VdS Schadenverhütung GmbH • Amsterdamer Straße 172-174 • D-50735 Köln

Notifizierte Zertifizierungsstelle für Bauprodukte • Kenn-Nummer 0786
Notified Certification Body for Construction Products • Registration No. 0786

EG-Konformitätszertifikat EC-Certificate of Conformity

0786 – CPD - 20322

Gemäß der Richtlinie 89/106/EWG des Rates der Europäischen Gemeinschaften vom 21. Dezember 1988 zur Angleichung der Rechts- und Verwaltungsvorschriften der Mitgliedstaaten über Bauprodukte (Bauproduktenrichtlinie – CPD), geändert durch die Richtlinie 93/68/EWG des Rates der Europäischen Gemeinschaften vom 22. Juli 1993, wird hiermit bestätigt, dass das Bauprodukt

In compliance with the Directive 89/106/EEC of the Council of European Communities of 21 December 1988 on the approximation of laws, regulations and administrative provisions of the Member States relating to the construction products (Construction Products Directive - CPD), amended by the Directive 93/68/EEC of the Council of European Communities of 22 July 1993, it has been stated that the construction product

Ansaugrauchmelder
Serien TITANUS MICRO-SENS®;
TITANUS RACK-SENS®

(Produktmerkmale siehe Anlage 1)

Aspirating Smoke Detector
Series TITANUS MICRO-SENS®;
TITANUS RACK-SENS®

(Product parameters see appendix 1)

in Verkehr gebracht durch

placed on the market by

WAGNER Group GmbH
Schleswigstraße 1 - 5
DE 30853 Langenhagen

und erzeugt im Herstellwerk

and produced in the factory

WAGNER Group GmbH
Schleswigstraße 1 - 5
DE 30853 Langenhagen

durch den Hersteller einer werkseigenen Produktionskontrolle sowie zusätzlichen Prüfungen von im Werk entnommenen Proben nach festgelegtem Prüfplan unterzogen wird und dass die notifizierte Stelle VdS Schadenverhütung GmbH eine Erstprüfung der relevanten Eigenschaften des Produkts, eine Erstinspektion des Werkes und der werkseigenen Produktionskontrolle durchgeführt hat und eine laufende Überwachung, Beurteilung und Anerkennung der werkseigenen Produktionskontrolle durchführt.

Dieses Zertifikat bescheinigt, dass alle Vorschriften über die Bescheinigung der Konformität und die Leistungseigenschaften, beschrieben im Anhang ZA der Norm(en)

is submitted by the manufacturer to a factory production control and to the further testing of samples taken at the factory in accordance with a prescribed test plan and that the notified body VdS Schadenverhütung GmbH has performed the initial type-testing for the relevant characteristics of the product, the initial inspection of the factory and of the factory production control and performs the continuous surveillance, assessment and approval of the factory production control.

This certificate attests that all provisions concerning the attestation of conformity and the performances described in the Annex ZA of the standard

EN 54-20: 2005

EN 54-17: 2005

angewendet wurden und dass das Produkt alle darin vorgeschriebenen Anforderungen erfüllt.

Dieses Zertifikat wurde erstmals am 25.01.2008 ausgestellt und gilt solange, wie die Festlegungen in der angeführten harmonisierten technischen Spezifikation oder die Herstellbedingungen im Werk oder die werkseigene Produktionskontrolle selbst nicht wesentlich verändert werden.

were applied and that the product fulfils all the prescribed requirements.

This certificate was first issued on 25.01.2008 and remains valid as long as the conditions laid down in the harmonised technical specification in reference or the manufacturing conditions in the factory or the FPC itself are not modified significantly.

Köln, 06.07.2009



Stahl

(ppa. Stahl)

Leiter der Zertifizierungsstelle
Head of Certification Body

EG-KONFORMITÄTSERKLÄRUNG

EC-DECLARATION OF CONFORMITY

über die Einhaltung der EMV-Schutzanforderungen
regarding the EMC protection requirements

Wir
We

WAGNER Alarm- und Sicherungssysteme GmbH
Schleswigstraße 5
D-30853 Langenhagen

erklären in alleiniger Verantwortung, dass das Produkt
hereby declare that the product

TITANUS MICRO·SENS®

auf das sich diese Erklärung bezieht, mit den folgenden Normen oder
normativen Dokumenten übereinstimmt.
meets the following standards or technical specifications.

EN 61000-6-3, EN 55022 KI.B
EN 50130-4:1996

Gemäß den Bestimmungen der Richtlinie 89/336/EWG des Rates zur
Angleichung der Rechtsvorschriften der Mitgliederstaaten über die
elektromagnetische Verträglichkeit.

In accordance with the Council Directive 89/336/EEC on the approximation of the laws of the
Member States relating to electromagnetic compatibility.

Langenhagen, den 17.12.2004

Leiter Entwicklung

i. A. P. Heinicke

WAGNER Alarm- und Sicherungssysteme GmbH, Schleswigstraße 5, D-30853 Langenhagen

Telefon (+49) 0511/97383-0
Telefax (+49) 0511/97383-140
Telefax (+49) 0511/97383-289
e-mail info@wagner.de
Internet www.wagner.de

GF: Dipl.-Ing. Werner Wagner
Sitz der Gesellschaft: Langenhagen
Amtsgericht Hannover, HRB 59923
USt.-Ident-Nr. DE 115119330
Steuer-Nr. 27/200/31040

Deutsche Bank Hannover
Konto 8 152 720, BLZ 25070070
S.W.I.F.T.-Code: DEUTBE2H
Kreissparkasse Hannover
Konto 2 048 957, BLZ 250 502 99

Hallbaum-Bank Hannover
Konto 10 154 243, BLZ 250 601 80
Postbank Hannover
Konto 123 626-308, BLZ 250 100 30

Testing record for Aspirating Smoke Detection System of the TITANUS MICRO · SENS[®] type

Device number						
Detection unit serial number						
Device base serial number						
	Measure/ + Setting	Measure / + Setting	Measure/ + setting	Measure/ + Setting	Measure/ + Setting	Measure/ + Setting
Commissioning						
Visual check (✓/–)						
Low pressure [Pa]						
Sensitivity [%/m]						
Alarm delay [s]						
Air flow range [10-50%]						
Fault delay [min]						
Fault storing (ja/nein)						
Dynamic air flow (ja/nein)						
Location (ja/nein)						
LOGIC · SENS (ja/nein)						
Air pressure-dependent adjustment (ja/nein)						
Air pressure-independent adjustment (ja/nein)						
Height [m ü. NN.]						
Air pressure [hPa]						
Ventilator voltage [9-13,5V]						
Air flow range [m/s]						
Temperature [°C]						
Blockage Fault						
LED flashing (✓/–)						
Relay drops out after delay time (✓/–)						
Signal forwarding to fire alarm system (✓/–)						
Cause removed, LED out (✓/–)						
Relay picks up after threshold undercut (✓/–)						
Cause removed, LED stored (✓/–)						
Relay remains down for at least 100 secs (✓/–)						
Break Fault						
LED flashing (✓/–)						
Relay drops out after delay time (✓/–)						
Signal forwarding to the FAS (✓/–)						
Cause removed, LED out (✓/–)						
Relay picks up after threshold undercut (✓/–)						
Cause removed, LED stored (✓/–)						
Relay remains down for at least 100 secs (✓/–)						
Main Alarm						
LED flashing (✓/–)						
Relay picks up after delay time (✓/–)						
Signal forwarding to FAS (✓/–)						
LED stored (✓/–)						
Relay stored (✓/–)						
Location (ROOM-IDENT)						
Free blow time [10-255s]						
Free blow ventilator [9-13,5V]						
Aspiration ventilator [9-13,5V]						
LED Location long-term aspiration aperture A (yes/no) / [s]						
LED Location long-term aspiration aperture B (yes/no) / [s]						
LED Location long-term aspiration aperture C (yes/no) / [s]						
LED Location long-term aspiration aperture D (yes/no) / [s]						
LED Location long-term aspiration aperture E (yes/no) / [s]						
Reaction Indicator						
Aspiration aperture A (yes/no)						
Aspiration aperture B (yes/no)						
Aspiration aperture C (yes/no)						
Aspiration aperture D (yes/no)						
Aspiration aperture E (yes/no)						

Issuer:

Signature:

Key: ✓ O.K.
– not O.K.

Glossary

<i>Technical Term</i>	<i>Definition</i>
A	
Aerosol Also: smoke aerosol	An aerosol is a floating particle in the microscopic or submicroscopic particle size range. It consists of unburned parts of the fire load, intermediate products of the oxidation and finely divided carbon (soot).
Air flow sensor	Sensor for monitoring the total air flow in the pipe system, i.e. checking the pipe system for blockage and fracture; depending on the demands of the air flow monitor →single-hole monitoring and the detection of a fracture at the end of the pipe system are possible.
Air sampling smoke detection system	An active system producing under-pressure for air sampling with a ventilator, integrated in the system. The air samples are then passed to a detection unit (smoke detector, detector head or detector module).
Alarm	<ul style="list-style-type: none"> a) Acoustic and/or optical signal activated through →smoke detectors to indicate a fire. b) Freely adjustable alarm threshold. The activation of the alarm definitely means the detection of a fire. The fire department is informed.
Alarm condition	The condition of a fire detection installation or a part of it as a reaction to an existing danger.
Alarm current	An increased voltage in the →alarm condition (→quiescent current).
Automatic smoke detectors	These detect and analyse physical parameters which lead to danger-warning signals. Automatic smoke detectors are e.g. point-type detectors and →air sampling smoke detection systems.
C	
Central fire panel	Central part of a fire detection installation which supplies the detectors with power, displays received signals optically and acoustically and, if required, transmits them and checks the installation for faults.
Collective detection system	Conventional line detection technology for which all detectors, connected to the same line, have the same collective address (common indication and operation without identification of the individual detector).

C	
Collective effect	A phenomenon common only to air sampling smoke detection systems. The sensitivity of the individual detection points (smoke sampling points), in contrast to point-type detectors, does not remain constant. The sensitivity of the individual air sampling points depends on the → response sensitivity and the number of air sampling points.
Collective fault	A non-differentiated, i.e. non-localisable →fault signal which reports to a superior system.
Contact load	Contact load describes the maximum load at which a relay contact can be switched.
D	
Detection line	Monitored transmission line (→primary line) to which the smoke detectors are connected with the →central fire panel.
Detection reliability	This is the measure of reliability with which phenomena are detected and reported and for which a detection system is used.
Detection unit	The sensitive detection unit is picking up smoke aerosols.
Detector group	Collection of smoke detectors in a →detection line for which a separate display is installed in the →central fire panel.
DIL switch	Dual In Line ; e.g. to set the response sensitivity, the air flow sensor, the delay period for →alarm and fault, to set the fault display to latched or non-latched and to activate or deactivate → LOGIC·SENS.
Drift	Method of compensating detector soiling which could change the quiescent signal by moving the zero point.
E	
Electromagnetic compatibility (EMC)	This is the ability of an electrical or electronic system to operate correctly in its electromagnetic environment and have no adverse affect on this environment.
End-of-line resistor	Element at the end of a →detection or control line to check the line for broken wires and short circuits.
F	
Fault signal	Signal indicating a deviation from the desired value in the →smoke detection installation.
Fire load	The fire load corresponds to the amount of heat of all combustible materials of a fire section, depending on its surface area.

Fire monitor	Part of a →central fire panel to identify fire in the protected area.
Fire section	Isolated section in a building (special construction) which avoids or slows down the spreading of a fire to a neighboring section.
Fire-resistant collar	Constructions which avoids flame/smoke spreading in cable ducts as well as in recesses and break-through for wiring in walls and ceilings.
I	
Interactive detector	Detector series with highest detection reliability for evaluation and decision logistics with interactive signal processing based on programmable algorithms. The detectors can be parameterized; they can be optimally programmed in software for the requirements of the installation location.
Interference	Interferences in smoke detection installations are external values which can impair the proper functioning of a smoke detection installation.
L	
Line module	By means of line modules (AnalogPLUS® or interactive) TITANUS MICRO·SENS® can be connected to the AlgoRex®-smoke detection system.
LOGIC·SENS	Via the LOGIC·SENS switch the intelligent signal processing can be activated. It permits analysis of the measured smoke level by comparing the smoke data with known parameters, thus detecting interferences and avoiding false alarms.
Loop line	→Detection line which forms a loop from the central fire panel via the →smoke detectors and back to the central fire panel to increase operation reliability.
M	
Monitoring area	Area which is monitored by an automatic smoke detector.
Monitoring window	The normal air flow lies within an adjustment range between a defined upper and lower value. This range is the monitoring window.
N	
Nominal gap width	Maximum gap in the housing of the detonation prevention device without an ignition spark being flashed from the device to the potentially explosive area.

P	
Primary line	Primary lines are transmission lines permanently and automatically checked for short circuit and interruption. They serve the transmission of important function signals of smoke detection systems.
Plug and Play	Installation and commissioning of the air sampling smoke detection system are simple with the Plug & Play function.
PIPE·GUARD	PIPE·GUARD , the comprehensive package for airflow monitoring, recognises safe breakdowns such as pipe breakages or blocked detection apertures.
Q	
Quiescent current	Current on the detection line in its normal operational state, →alarm current
R	
Response sensitivity	The response sensitivity describes the sensitivity at which an alarm is activated (→detector module sensitivity).
ROOM·IDENT	The ROOM·IDENT technology makes it possible to locate a fire in seat monitoring up to 5 separate areas.
S	
Scattered light smoke detectors	Scattered light smoke detectors are optical smoke detectors. They use the phenomenon of scattered light through smoke particles which changes the signal at the light diode.
Secondary line	Non-monitored transmission lines.
Sensitivity	The TITANUS MICRO·SENS® reaction threshold can be set at between 0.5 %/m and 2 %/m light extinction in steps of 0.1%/m.
Single hole monitoring	Detection of changes (e.g. blockages) of the diameter of each single air sampling point.
Smoke detector	Smoke detectors react to combustible particles and/or →aerosols (floating particles) in the air.
T	
Temperature compensation	The air flow in the pipe system is not falsified by temperature variations when using temperature compensation.

Two-detector dependency	A system to verify alarm states. The fire alarm is activated after two detectors of a →detector group have raised the alarm. When the first detector has given an internal alarm a control function can be activated.
Two-group dependency	System to verify alarm states. The fire alarm is activated after one detector of each of two related →detector groups have raised the alarm.
V	
Value concentration	The value concentration is an important factor for the evaluation of the risk of fire. It is calculated with the values to be protected. An added consideration is the replace ability of the endangered goods, which will be nearly impossible in the case of cultural assets.

Conformity certification pursuant to EU Construction Products Directive 89/106/EEC

- The conformity of the „**air sampling smoke detector for fire detection and fire alarm systems in buildings**“ according to DIN EN 54-20 has been established by a test at the VdS laboratory.
- The EC certificate of conformity has been issued by notified product certification body (ID no. 0786, VdS).
- The CE designation according to DIN EN 54-20 has been carried out.



0786

WAGNER Group GmbH
Schleswigstrasse 1 - 5 30853 Langenhagen
09
Nr. 0786 – CPD – 20322

EN 54-20: 2006

Air sampling smoke detector for fire detection
and fire alarm systems in buildings

0,1 % light obscuration/m
Class: A, B and C

0,5 % light obscuration/m
Class: A, B and C

Technical data: see chapter 3 of technical manual.

WAGNER Group GmbH

Hauptsitz
Schleswigstraße 1 - 5
D-30853 Langenhagen
☎ +49 (0) 511 - 973 83-0
✉ +49 (0) 5 11- 97383-260
support@wagner.de

Deutschland:

WAGNER Group GmbH
Niederlassung Berlin
Am Müggelpark 19
D-15537 Gosen-Neu Zittau
☎ +49 (0)3362 - 7406 - 0
✉ +49 (0)3362 - 7406 -19
berlin@wagner.de

WAGNER Group GmbH
Niederlassung Berlin - Büro Leipzig
Zeppelinstraße 2
D-04509 Wiedemar
☎ +49 (0)34207 - 645-0
✉ +49 (0)34207 - 645-19
leipzig@wagner.de

WAGNER Group GmbH
Niederlassung Hamburg
Stuvenborner Straße 8A
D-24643 Struvenhütten
☎ +49 (0)4194 - 9970-0
✉ +49 (0)4194 - 9970-99
hamburg@wagner.de

WAGNER Group GmbH
Niederlassung Hannover
Schleswigstraße 3
D-30853 Langenhagen
☎ +49 (0)511 - 97383-0
✉ +49 (0)511- 97383-140
hannover@wagner.de

Europa:

WAGNER Austria GmbH
Am Hafen 6
A-2100 Korneuburg
☎ +43 (0)2262 - 64262 -0
✉ +43 (0)2262 - 64262-19
office@wagner-austria.com

WAGNER SCHWEIZ AG
Industriestrasse 44
CH-8304 Wallisellen
☎ +41 (0)44 - 8325400
✉ +41 (0)44 - 8325409
info@wagner-schweiz.ch

Middle East:

WAGNER Middle East FZE
Dubai Airport FreeZone Authority
P.O. Box 54651
Building E2, Room 105
Dubai U.A.E
☎ + 971 (0) 4299 0887
✉ + 971 (0) 4299 1799
info@wagner-arabia.com

WAGNER Group GmbH
Niederlassung Mülheim/Ruhr
Reichstraße 37-39
D-45479 Mülheim a.d. Ruhr
☎ +49 (0)208 - 41995-0
✉ +49 (0)208 - 41995-13
muelheim@wagner.de

Wagner Group GmbH
Niederlassung Mülheim/Ruhr -
Vertriebsbüro Köln
Lukasstraße 30
D-50823 Köln
☎ +49 (0)0221 - 9524203
✉ +49 (0)0221 - 9524217
muelheim@wagner.de

WAGNER Group GmbH
Niederlassung Frankfurt
Siemensstraße 1
D-61239 Ober-Mörlen
☎ +49 (0)6002 - 9106-0
✉ +49 (0)6002 - 9106-19
frankfurt@wagner.de

WAGNER Group GmbH
Niederlassung Stuttgart
Schwieberdingerstraße 60/1
D-71636 Ludwigsburg
☎ +49 (0)7141 - 488798-0
✉ +49 (0)7141- 488798-19
stuttgart@wagner.de

WAGNER Nederland B.V.
Manitobadreef 11, 3565 CH Utrecht
Postbus 9752
NL-3506 GT Utrecht
☎ +31 (0)30 - 2200264
✉ +31 (0)30 - 2201917
info@wagner-nl.com

WAGNER Poland Sp. z o.o. i Sp. k.
ul. Puławska 38
PL 05-500 Piaseczno
☎ +48 (0)22 - 7263550
✉ +48 (0)22 - 7263551
info@wagnerpoland.pl

WAGNER Bayern GmbH
Tausnitzstraße 8
D-81671 München
☎ +49 (0)89 - 450551-0
✉ +49 (0)89 - 450551-99
muenchen@wagner.de

Wagner Bayern GmbH
Vertriebsbüro Illertissen
Dietenheimer Str. 19 b
D-89257 Illertissen
☎ +49 (0)07303 - 95191 -12
✉ +49 (0)07303 - 95191 -99
muenchen@wagner.de

WAGNER UK Limited
Wagner House - Unit F
South Cambridge Business Park
Babraham Road
Sawston
Cambridge CB22 3JH
☎ +44 (0)870 - 3336116
✉ +44 (0)870 - 3334544
info@wagner-uk.com

